

Automatic Port Configuration for Dell EMC Networking N-Series Switches

Dell EMC Networking Solutions Engineering May 2017

Revisions

Date	Description	Authors
May 2017	Initial Release v1.0	Victor Teeter, Ravindra Kadiyala, Asha Chen-Phang

THIS WHITE PAPER IS FOR INFORMATIONAL PURPOSES ONLY, AND MAY CONTAIN TYPOGRAPHICAL ERRORS AND TECHNICAL INACCURACIES. THE CONTENT IS PROVIDED AS IS, WITHOUT EXPRESS OR IMPLIED WARRANTIES OF ANY KIND.

Copyright © 2017 Dell Inc. or its subsidiaries. All Rights Reserved. Except as stated below, no part of this document may be reproduced, distributed or transmitted in any form or by any means, without express permission of Dell.

You may distribute this document within your company or organization only, without alteration of its contents.

THIS DOCUMENT IS PROVIDED "AS-IS", AND WITHOUT ANY WARRANTY, EXPRESS OR IMPLIED. IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE SPECIFICALLY DISCLAIMED. PRODUCT WARRANTIES APPLICABLE TO THE DELL PRODUCTS DESCRIBED IN THIS DOCUMENT MAY BE FOUND AT: <u>http://www.dell.com/learn/us/en/vn/terms-of-salecommercial-and-public-sector-warranties</u>

Performance of network reference architectures discussed in this document may vary with differing deployment conditions, network loads, and the like. Third party products may be included in reference architectures for the convenience of the reader. Inclusion of such third party products does not necessarily constitute Dell's recommendation of those products. Please consult your Dell representative for additional information.

Trademarks used in this text: Dell[™], the Dell logo, Dell Boomi[™], PowerEdge[™], PowerVault[™], PowerConnect[™], OpenManage[™], EqualLogic[™], Compellent[™], KACE[™], FlexAddress[™], Force10[™] and Vostro[™] are trademarks of Dell Inc. EMC VNX®, and EMC Unisphere® are registered trademarks of Dell. Other Dell trademarks may be used in this document. Cisco Nexus®, Cisco MDS®, Cisco NX-0S®, and other Cisco Catalyst® are registered trademarks of Cisco System Inc. Intel®, Pentium®, Xeon®, Core® and Celeron® are registered trademarks of Intel Corporation in the U.S. and other countries. AMD® is a registered trademark and AMD Opteron[™], AMD Phenom[™] and AMD Sempron[™] are trademarks of Advanced Micro Devices, Inc. Microsoft®, Windows®, Windows Server®, Internet Explorer®, MS-DOS®, Windows Vista® and Active Directory® are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. Red Hat® and Red Hat® Enterprise Linux® are registered trademarks of Red Hat, Inc. in the United States and/or other countries. Novell® and SUSE® are registered trademarks of Novell Inc. in the United States and other countries. Oracle® is a registered trademark of Oracle Corporation and/or its affiliates. VMware®, Virtual SMP®, vMotion®, vCenter® and vSphere® are registered trademarks or trademarks of VMware, Inc. in the United States or other countries. IBM® is a registered trademark of International Business Machines Corporation. Broadcom® and NetXtreme® are registered trademarks of QLogic Corporation. Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and/or names or their products and are the property of their respective owners. Dell disclaims proprietary interest in the marks and names of others.

Contents

1	Intro	duction	5
	1.1	Purpose of this document	5
	1.2	Supported switches	6
	1.3	Attachable IP devices	6
2	Unde	erstanding CLI macros	8
	2.1	Built-in macros	8
	2.2	Passing parameters	11
	2.3	Custom macros	12
3	Crea	ting the Auto Port Profile scripting tool	15
	3.1	Py (Python) script file: autoport.py	16
	3.2	PRM (parameter) file: autoport.prm	25
4	Apply	ying and executing the Python script (with PRM file)	27
	4.1	Validating script behavior	28
5	Disal	bling the script	29
6	Auto	Port Profile script flowchart	30
7	Trou	bleshooting	31
8	Best	practices and tips	34
	8.1	Planning and creating scripts	34
	8.2	Testing scripts	34
	8.3	Deploying and maintaining scripts	35
9	Com	mand quick reference	36
А	Glos	sary of Terms	37
В	Devi	ce identification using LLDP	38
С	Additional Resources		
D	Supp	ort and Feedback	41

Executive Summary

Within an autonomous network, administrators are often responsible for dozens of network switches and hundreds of network ports. Each port can provide network connectivity to one of many device types including laptops, servers, storage, wireless access points (AP), IP phones, cameras, clocks, printers, lights, controllers, monitors, sensors, routers, and other switches. Each device type typically requires a different set of commands to configure the port in which the device is plugged in. The majority of ports in a switch are typically used and it is the responsibility of the network administrator to provide and maintain the proper configuration for the switch and each port.

This guide provides an efficient method of automating Dell EMC Networking N-Series switches to detect devices being plugged into those switches. The method further allows the switches to automatically configure the corresponding ports for those devices. This Auto Port Profile feature allows for minimal effort on the part of the network administrator when attaching devices, while decreasing the chance of human error.

Introduction

1

This document is a supplement to the *Dell EMC Networking N-Series User Guides* listed in the *Additional Resources* section on page 38. The step-by-step instructions provide examples to help network administrators configure Dell EMC Networking N-Series switches to detect when devices are being plugged into a switch, then automatically configures the corresponding ports for those devices. Two existing Dell EMC Networking N-Series features, Python scripting and CLI macros, are joined to implement this efficient method of automatic port provisioning.

Python scripting

Dell EMC Networking N-Series switches with firmware 6.3.x.x and later support installation and execution of Python applications to assist in configuring these switches. Network administrators often take advantage of this feature when they have several switches requiring configuration changes at once, or when one or more switches require frequent changes. Scripting allows efficiencies in performing management tasks such as regular backups of switch configurations or firmware updates. Any number of CLI commands may be automated with the use of a Python script. Dell EMC Networking N-Series supports Python version 2.7.10.

CLI macros

-

CLI macros provide a convenient way to save and distribute common configurations. A CLI macro is a set of the CLI commands having a unique name. When a CLI macro is applied, the commands contained within the macro are executed and added to the running-configuration. When the macro is applied to an interface, the existing configuration is not lost. Instead, the new commands are added to the configuration. N-Series switches offer several pre-defined, built-in CLI macros that may be applied to one or more interfaces on a switch to quickly configure their settings. Up to 50 user-defined, custom macros are also supported. This guide discusses the use of both custom and built-in instances.

A Python script example is provided in this guide that allows a switch to automatically detect new devices as they are connected to the switch, and then applies the appropriate CLI macros to configure the corresponding ports.

1.1 Purpose of this document

. ..

Table 1 provides details regarding the purpose of this guide:

l able 1 Is/Is not		
This guide is / does	This guide is not / does not	
a supplement to the N-Series User Guide	a Python reference manual	
an instruction guide for how to create custom scripts	contain completed scripts for every situation	
show examples for automating configurations	include scripts for all device types	
for Dell EMC N-series switches running DNOS	a guide for C-Series, S-Series or other switches	
provided to help network administrators who use Python understand it's capabilities on N-Series	imply or claim that Dell EMC maintains or supports any example scripts within	

1.2 Supported switches

Examples in this guide use Dell EMC Networking N2024P, N2128PX-ON, and N3048P switches. However, scripts and commands shown in this guide will run on any N-Series switches with firmware version 6.3 or later, including:

N1524, N1524P, N1548, N1548P, N2024, N2024P, N2048, N2048P, N2128PX-ON, N3024, N3024F, N3024P, N3048, N3048P, N3132PX-ON, N4032, N4032F, N4064, N4064F

This guide describes implementations that typically use PoE switches and devices. However, non-PoE switches and devices may also take advantage of these automation features.

Note: Dell EMC strongly advises switch administrators to maintain Dell EMC Networking N-Series switches with the latest version of the Dell EMC Networking Operating System.

For critical infrastructure, Dell EMC recommends prestaging new releases into a non-critical portion of the network to verify configurations and operations prior to installing into a production environment.

1.3 Attachable IP devices

Figure 1 demonstrates how a variety of devices can be physically connected to an Ethernet network switch. Each port where a device is attached requires specific commands to properly configure the switch to allow the attached device to effectively communicate with the rest of the network. Wireless APs, IP phones, cameras, and other devices are just a small sample of the types of equipment available on the market today that can be employed over an Ethernet network.



Figure 1 Example IP devices attached to an Ethernet switch for passing network traffic

The network administrator can decide which device types they want to support for automatic port configuration and program their script accordingly. This guide uses IP phones, Wireless APs, and other switches as examples. This device list can easily be modified with other device types.

Though Power over Ethernet (PoE) switches and devices are typically used for the type of implementation described throughout this guide, non-PoE switches and devices may also take advantage of these automation features. PoE only allows for the connected devices to be powered through the network cable.

When using the method and scripts provided in this guide, the N-Series switch must be up and running prior to connecting end devices that are expected to be automatically configured. The examples start with a minimal configuration and only contain a user id, password, and management IP address.

2 Understanding CLI macros

The Python script example provided in this guide allows you to add support for any number of end-user devices expected to attach to your switch. You may choose which macros to include in your script based on the type of devices you anticipate attaching. Dell EMC recommends selecting and testing the CLI macros required for the job prior to automating and implementing on a large scale.

CLI macros may have up to three variables replaced by values provided from a parameters (.prm) file upon application of the macro. Macros can be applied to specific interfaces, a range of interfaces, or the global configuration.

Note: Variables are often referred to as keys. Both terms are used in this guide.

There are two types of macros:

- Built-In: predefined macros available in the switch OS, which cannot be changed or deleted.
- *Custom*: user-defined macros, which allow the operator to bundle multiple built-in macros and/or add-remove commands as desired. Up to 50 user-defined macros are supported.

2.1 Built-in macros

There are two types of built-in macros. *Global* macros add commands to the global configuration of the switch, while *interface* macros add commands directly to one or more interfaces on the switch. There are two global macros (profile-global and profile-compellent-nas) and five interface macros. Run the **show parser macro brief** command to see a summarized list of all built-in macros available on the N-Series switch.

```
N3024P#show parser macro brief
```

```
default global: profile-globaldefault interface: profile-desktopdefault interface: profile-phonedefault interface: profile-switchdefault interface: profile-routerdefault interface: profile-wirelessdefault global: profile-compellent-nas
```

Run the **show parser macro** command for a detailed list of the built-in macros including all commands contained within each macro. Notice that each keyword variable starts with a dollar sign (\$). Each of these keywords requires an external parameter be passed to it to complete the command. Up to three keys may be passed to a macro file. Section 2.2 Passing parameters provides an example of how to pass parameters when executing the macro from a command line.

command and output

description

console#show parser macro
Total number of macros = 7
______Macro name : profile-global
Macro type : default global

Beginning of the profile-global macro. The profile-

classofservice dot1p-mapping 5 5 classofservice dot1p-mapping 6 6 classofservice dot1p-mapping 7 6 # Enable RSTP and Loopquard spanning-tree mode rstp spanning-tree loopguard default -----Macro name : profile-desktop Macro type : default interface # macro keywords \$access vlan # Basic interface - Enable data VLAN only # Recommended value for access vlan should not be 1 switchport mode access switchport access vlan \$access_vlan # Port Security is enabled to limit # to 1 MAC address (desktop MAC) on the port switchport port-security switchport port-security dynamic 1 # Configure port as an edge network port spanning-tree portfast _____ Macro name : profile-phone Macro type : default interface # IP phone + desktop template # macro keywords \$general_vlan \$voice_vlan # Data vlan (general vlan) and voice vlan (voice vlan) # are both active for the VoIP-enabled interface # Recommended value for general vlan should not be 1 switchport mode general switchport general pvid \$general_vlan # Update the Voice VLAN value which should be # different from data VLAN # Recommended value for voice vlan should not be 1 Automatic Port Configuration for Dell Networking N-Series | v1.0

Config Cos to DSCP mappings

classofservice ip-dscp-mapping 0 0

classofservice ip-dscp-mapping 8 1

classofservice ip-dscp-mapping 16 2

classofservice ip-dscp-mapping 24 3

classofservice ip-dscp-mapping 32 4 classofservice ip-dscp-mapping 40 5 classofservice ip-dscp-mapping 46 6 classofservice ip-dscp-mapping 56 6

classofservice dot1p-mapping 0 0 classofservice dot1p-mapping 1 1 classofservice dot1p-mapping 2 2 classofservice dot1p-mapping 3 3 classofservice dot1p-mapping 4 4

> Beginning of the profile-desktop macro. The profiledesktop macro sets the preferred interface configuration for PCs and laptops attaching to the

switch.

global macro

contains several

global configuration

settings for devices

that commonly use

CoS and DSCP.

Beginning of the profile-phone macro. The profilephone macro sets the preferred interface configuration for attached IP phones.

9

Automatic Port Configuration for Dell Networking N-Series | v1.0

10

on the port (desktop mac and phone mac) switchport port-security switchport port-security dynamic 2 # Enable auto-gos to extend trust to attached phone voice vlan data priority trust # Configure port as an edge network port spanning-tree portfast # Add port to \$general_vlan as untagged# and to \$voice vlan as tagged member.# Also remove it from a default VLAN switchport general allowed vlan add \$general_vlan switchport general allowed vlan add \$voice_vlan tagged switchport general allowed vlan remove 1 _____ Macro name : profile-switch Beginning of the Macro type : default interface profile-switch macro. The profile-# macro keywords \$native_vlan switch macro sets # Connection to another switch and/or uplink the preferred switchport mode trunk # Native VLAN defaults to 1 if it has not been specifically defined. switchport trunk native vlan \$native_vlan # Include all VLANs on Trunk. switchport trunk allowed vlan all _____ Macro name : profile-router Macro type : default interface # macro keywords \$native_vlan # Connection to another switch and/or uplink. switchport mode trunk attached network # Native VLAN defaults to 1 if it has not been

Port Security is enabled to limit to 2 MAC addresses

specifically defined. switchport trunk native vlan \$native_vlan

Include all VLANs on Trunk. switchport trunk allowed vlan all

voice vlan \$voice vlan

Configure gos to trust this interface classofservice trust ip-dscp _____

Macro name : profile-wireless Macro type : default interface

macro keywords \$native_vlan # Connection to another switch and/or uplink. switchport mode trunk

Beginning of the profile-wireless macro. The profile-wireless macro sets the preferred interface

interface configuration for attached network switches. Beginning of the profile-router

macro. The profilerouter macro sets the preferred interface configuration for

routers.

Native VLAN defaults to 1 if it has not been specifically defined. switchport trunk native vlan \$native vlan # Include all VLANs on Trunk. switchport trunk allowed vlan all # Configure qos to trust this interface classofservice trust ip-dscp -----Macro name : profile-compellent-nas Macro type : default global # macro keywords \$interface_name # Compellent NAS macro flowcontrol system jumbo mtu 9216 interface \$interface name no storm-control unicast spanning-tree portfast

configuration for attached Wireless APs.

Beginning of the profile-compellentnas macro. This macro contains several global settings for traffic tuning of Compellent NAS devices. See the N-Series User Guide for more information on using this macro.

2.2 Passing parameters

exit

Scripts often contain variables that allow for users to pass unique values to the script in the form of parameters. This prevents the need to hard-code the macro script each time it is to be used in a slightly different capacity.

Variables contained in the profile scripts are indicated by a dollar sign (\$) as the first character. Each variable, or keyword, requires an external parameter be passed to it to complete the command. The below CLI output demonstrates how to manually pass parameters when executing the macro from a command line.

Commands are provided showing an example (**profile-phone**) macro being applied to interface gi1/0/1. This macro requires two parameters in order for it to work: *\$general_vlan* and *\$voice_vlan*. This example begins by showing no IP phone configuration present on the interface.

console # show running-config interface gigabitethernet 1/0/1

Create VLANs that may be applied to any switch interface:

```
console#config
console(config)#vlan 10,20
console(config-vlan10,20)#exit
```

Apply the profile-phone macro to the interface while passing it the two VLAN parameters:

console(config)#interface gigabitethernet 1/0/1

11 Automatic Port Configuration for Dell Networking N-Series | v1.0

```
console(config-if-Gi1/0/1)#macro apply profile-phone $general_vlan 10
$voice_vlan 20
console(config-if-Gi1/0/1)#exit
console(config)#exit
```

Re-run the show command to display the new port settings:

```
console#show running-config interface gigabitethernet 1/0/1
spanning-tree portfast
switchport mode general
switchport general pvid 10
switchport general allowed vlan add 10
switchport general allowed vlan add 20 tagged
switchport general allowed vlan remove 1
switchport port-security
switchport port-security dynamic 2
voice vlan 20
macro description profile-phone
```

Note: The **show running-configuration** command shows the comment "macro description profile-xxxx" on all interface configurations where a macro was used in configuring the interface.

2.3 Custom macros

The Dell EMC Networking N-Series switch also gives the user the ability to create their own custom macros. This may be necessary if none of the built-in macros provide the desired configuration needed for a port.

In the example below, a custom macro *profile-shaper* is created. The new macro is then modified to be used for traffic shaping when devices requiring 60Mbps speeds are discovered on a 1Gbps port. The commands in bold are ran from the CLI prompt.

Display the list of macros available:

```
console#show parser macro brief

default global : profile-global
default interface : profile-desktop
default interface : profile-phone
default interface : profile-switch
default interface : profile-router
default interface : profile-wireless
default global : profile-compellent-nas
```

console#configure t

console(config)#macro name profile-shaper Enter macro commands one per line. End with the character '@'. #configure trunk port switchport mode trunk #allowed vlans from the vlan list switchport trunk allowed vlan add \$vlanList #configure traffic shape in kpbs traffic-shape \$rate kbps #description of an interface description \$description no shutdown @

Note: Using cut and paste can provide a shortcut for creating a custom macro. Use the show parser macro name <existing macro> to show the commands in the existing macro. Copy the commands into the custom macro then modify it to suit specific needs.

Apply and confirm the custom macro on the port:

```
console(config)#interface gigabitethernet 1/0/1
console(config-if-Gi1/0/1)#macro apply profile-shaper $vlanList 5-500 $rate
60000 $description uplink1
console(config-if-Gi1/0/1)#show running-config interface gigabitethernet 1/0/1
```

traffic-shape 60000 kbps
description "uplink1"
switchport mode trunk
macro description profile-shaper

Display the custom macro information:

```
console(config-if-Gi1/0/1)#show parser macro name profile-shaper
Macro name : profile-shaper
Macro type : customizable
#configure trunk port
switchport mode trunk
#allowed vlans 5-500 only
switchport trunk allowed vlan add $vlanList
#configure traffic shape in kbps
```

traffic-shape \$rate kbps
#description of an interface
description \$description
no shutdown

List all built-in and custom macros:

console(config-if-Gi1/0/1)#show parser macro brief
 default global : profile-global
 default interface : profile-desktop
 default interface : profile-phone
 default interface : profile-switch
 default interface : profile-router
 default interface : profile-wireless
 default global : profile-compellent-nas
 customizable : profile-shaper

Saving the switch configuration

When a configuration is applied from a built-in, custom, global, or interface macro, it is only applied to the running-configuration. The running-configuration must be copied to the startup-configuration in order for the new configuration commands to be persistent after a reboot. In this respect, the changes brought about by the macro are no different than any other configuration changes made manually at the command line. The running configuration keeps the new configuration until one of the following events occur:

- The user manually removes the configuration lines from the CLI
- The user overwrites one or more lines of configuration using different options
- A macro is run on the switch that performs one of the above actions
- The switch reboots (unless the running-configuration was saved beforehand to the startupconfiguration)

Once it is determined the running-configuration is working as desired, use the command below to copy the running-configuration to the startup-configuration.

console#copy running-configuration startup-configuration

Creating the Auto Port Profile scripting tool

The Auto Port Profile scripting tool uses the macros discussed in Chapter 2 along with the switch's Python capabilities (polling, parsing, etc.) to automate port configurations. Link Layer Discovery Protocol (LLDP) packet information entering the switch is used to identify the type of device being connected to the switch in order to apply an applicable switch configuration to the corresponding interface.

A Python script file (with .py extension) and associated parameter file (with .prm extension) are used to enable the Auto Port Profile capability. Examples of both the Auto Port Profile script and the parameter file are presented below to demonstrate Auto Port Profiling in the use case scenario represented in Figure 2. The script is titled **autoport.py**, and the parameter file is titled **autoport.prm**. Both filenames are user-defined and limited to 15 characters. *Chapter 6 Auto Port Profile script flowchart* on page 30 illustrates an example sequence of the development and execution of these files.

Figure 2 shows three departments (Engineering, Finance, and Human Resources) within a company where the network administrator has a switch configured with VLANs for each department. The administrator anticipates IP phones, Wireless APs, and other switches may be connected in the future and wants to automate configuring of the switch ports. The appropriate settings are applied to the interface when one of these three device types is identified on a port





Creating and applying the Python and PRM files below enables the Dell EMC Networking N-Series switch interfaces to be automatically configured as devices are attached.

Figure 3 shows the desired VLAN assignment for each device type as it is cabled to the switch.



Figure 3 Assigning VLANs to attached devices

Use the autoport.py script below to enable the Auto Port Profile capability. Be sure to create the file from your Windows or Linux desktop with a scripting editor that uses plain text character encoding (UTF-8 or ASCII).

3.1 Py (Python) script file: autoport.py

autoport.py script example	description
#!/usr/bin/env python # File : autoportconfig.py #	Provide python script statements and comments as needed
#author = "Ravindra Kadiyala & Asha Chen-	
Phang"	
version = "1.0" date = "\$Feb 6 2017\$"	

```
#import require modules
                                                       Import all required modules.
                                                       See the Python Scripting
import telnetlib
                                                       for Dell EMC Networking N-
import sys
                                                       Series guide for a list of
import time
                                                       supported modules
import re
import socket
import imp
import logging
#variable initialization
                                                       Initiate variables
global enablePrompt
global configPrompt
configPrompt = '#'
enablePrompt = '>'
                                                       Define local functions
#define local functions
def logintelnet(host,user, password):
    """This function will use to open telnet
                                                       Open telnet session to
session to the switch"""
                                                       switch
    try:
        spawn_id = telnetlib.Telnet(host)
        read = spawn_id.read_until
        write = spawn_id.write
        read('User:')
        write(user + ' r')
        read('Password:')
        write(password + ' r')
        authcheck = read(enablePrompt)
        if 'User:' in authcheck:
             logger.error('ERROR-Authentication
failure')
            return False
        write('enable\r')
        read(configPrompt)
    except (socket.timeout, EOFError) as err:
        er = 'ERROR-timeout/EOF:'+ str(err)
        logger.error(er)
        return False
    return spawn_id
def setlldptimers(session, interval, hold):
                                                       Configure LLDP interval
    """This function will use to configure lldp
                                                       and hold timers
interval and hold timers"""
    write = session.write
    read = session.read_until
    try:
        write('\r')
        read(configPrompt)
        write('configure terminal\r')
        read(configPrompt)
```

```
write('lldp timers interval ' +
str(interval) + ' r'
        read(configPrompt)
        write('lldp timer hold ' + str(hold)
+'\r')
        read(configPrompt)
        write('exit\r')
        read(configPrompt)
    except Exception as err:
        er = 'ERROR-Fail to configure lldp
                                                      Display error if failure
timers:' + str(err)
                                                      occurs
        logger.error(er)
        return False
    return True
def getlldpifname(session):
    """This function is used to get lldp
                                                      Obtain LLDP interface
interface list on the switch"""
                                                      listing from the switch
    write = session.write
    read = session.read until
    try:
        write('\r')
        read(configPrompt)
        write('terminal length 0\r')
        read(configPrompt)
        write('show lldp remote-device all\r')
        lldpdetails = read(configPrompt)
        gigint = re.compile("^Gi\d/\d/\d+",
re.MULTILINE)
        gigintlist = gigint.findall(lldpdetails)
        teint = re.compile("^Te\d/\d/\d+",
re.MULTILINE)
        teintlist = teint.findall(lldpdetails)
        lldpiflist = gigintlist + teintlist
    except Exception as err:
        er = 'ERROR-Fail to get lldp interfaces
                                                      Display error if failure
info:' + str(err)
                                                      occurs
        logger.error(er)
        return False
    return lldpiflist
def readparams(filename):
    """This function will use to read the
                                                      Read parameters from the
parameters from the .prm file"""
                                                      parameter (.prm) file
    try:
        f = open(filename)
        global params
        params = imp.load_source('params', "",
f)
        f.close()
    except Exception as err:
```

```
er = 'ERROR-Fail to read parameter
                                                       Display error if failure
                                                       occurs
file:' + str(err)
        logger.error(er)
        return False
    return True
def getlldpdetails(session, ifname):
    """This function will use to get lldp
                                                       Retrieve LLDP details from
remote-device details on the switch"""
                                                       device connecting to the
    write = session.write
                                                       switch
    read = session.read until
    retval =[]
    try:
        write('\r')
        read(configPrompt)
        write('terminal length 0\r')
        read(configPrompt)
        for i in ifname:
             write('show lldp remote-device
detail' +' '+ i +' \r')
             output = read(configPrompt)
             portid =
re.search('(?<=Port\sID:\s).+\S', output)</pre>
             sysname =
re.search('(?<=System\sName:\s).+\S', output)</pre>
             sysdesc =
re.search('(?<=System\sDescription:\s).+\S',
output)
             portdesc =
re.search('(?<=Port\sDescription:\s).+\S',</pre>
output)
             syscapsupp =
                                                        Retrieve system capabilities
re.search('(?<=Capabilities\sSupported:\s).+\S',
                                                       supported by the device to
output)
                                                       identify device type
             syscapen =
re.search('(?<=Capabilities\sEnabled:\s).+\S',</pre>
                                                        Retrieve system capabilities
                                                        enabled on the device to
output)
                                                       identify device type
             lldpfields = [portid, portdesc,
syscapsupp, syscapen, sysdesc]
             for field in lldpfields:
                 if field != None:
lldpfields[lldpfields.index(field)] =
field.group()
             res = { 'interface':i, 'portid':
lldpfields[0],'portdesc':
lldpfields[1],'syscapsupp':
lldpfields[2],'syscapen': lldpfields[3
],'sysdesc':lldpfields[4]}
             retval.append(res)
```

```
except Exception as err:
                                                      Display error if failure
                                                      occurs
        er = 'ERROR- getlldpdetails:' + str(err)
        logger.error(er)
        retval = False
    return retval
                                                      Convert an interface range
def converttolist(intlist):
                                                      to a list
    """This function will use to convert
interfaces range to list"""
    ret = []
    iflist= intlist.split()
    try:
        for index in range(0,len(iflist)):
             if '-' in iflist[index]:
                 splitint = intlist.split('-')
                 intind1 = splitint[0]
                 intind2 = splitint[1]
                 splitind1 = intind1.split('/')
                 splitind2 = intind2.split('/')
                 ifid1 = splitind1[-1]
                 ifid2 = splitind2[-1]
                 for x in
range(int(ifid1),int(ifid2)+1):
                     res = str(intind1[0:6]) +
str(x)
                     ret.append(res)
             else:
                 ret.append(iflist[index])
    except Exception as err:
        er = 'ERROR-Fail to convert interfaces
                                                      Display error if failure
to list:' + str(err)
                                                      occurs
        logger.error(er)
    return ret
def applymacro(session,lldpdata):
    """This function will apply macro on the
                                                      Function to apply the
                                                      appropriate macro
switch"""
    write = session.write
    read = session.read until
                                                      Display error if failure
    macroerr = ['Error', 'No value', 'does not',
                                                      occurs
'Invalid']
    macroprm =[]
    ret = True
    var = vars(params).keys()
    for index in var:
        if '_' not in index:
            macroprm.append(index)
    try:
        for ind in range(0, len(lldpdata)):
```

```
lldpdict = lldpdata[ind]
             interface = lldpdict['interface']
             syscap = lldpdict['syscapsupp']
             sysdesc = lldpdict['sysdesc']
             deptlist = []
             for i in macroprm:
deptlist.append(getattr(params,i))
             if syscap !=None:
                 for dept in deptlist:
                     time.sleep(2)
                     if interface in
converttolist(dept['intrange']):
                          macroint = interface
                                                       Apply switch macro to
                          if 'router' in syscap:
                                                       interfaces with attached
                              description = 'Found
                                                       switches
' + sysdesc + 'on interface ' + str(interface)
string = 'Applying switch macro to an interface
                                                       Set description string of
- '+ str(interface)
                                                       discovered device and port
                          logger.info(description)
                              logger.info(string)
                                                       Log INFO level messages
                              macroname =
dept['switch']
                              write('\r')
                              read(configPrompt)
                              write('configure
terminal\r')
                              read(configPrompt)
                              write('interface ' +
macroint+'\r')
                              read(configPrompt)
                              write(macroname
+'\r')
                              output =
read(configPrompt)
                              write('endr')
                              read(configPrompt)
                              for error in
                                                       Display error if failure
macroerr:
                                                       occurs
                                   if error in
output:
                                       er = 'ERROR-
Fail to apply macro: '+ str(output)
logger.error(er)
                                       ret = False
                          elif 'telephone' in
                                                       Apply telephone macro to
syscap:
                                                       interfaces with attached
                                                       telephones
                              description = 'Found
' + sysdesc + 'on interface ' + str(interface)
```

```
string = 'Applying
                                                        Set description string of
                                                        discovered device and port
telephone macro to an interface - '+
str(interface)
                          logger.info(description)
                                                        Log INFO level messages
                               logger.info(string)
                               macroname =
dept['telephone']
                               write('\r')
                               read(configPrompt)
                               write('configure
terminal r')
                               read(configPrompt)
                               write('interface ' +
macroint+'\r')
                               read(configPrompt)
                               write(macroname
+'\r')
                               output =
read(configPrompt)
                               write('end\r')
                               read(configPrompt)
                               for error in
macroerr:
                                   if error in
output:
                                                        Display error if failure
                                        er = 'ERROR-
                                                        occurs
Fail to apply macro:' + str(output)
logger.error(er)
                                        ret = False
                          elif 'WLAN access point'
                                                        Apply Wireless AP macro to
in syscap:
                                                        interfaces with AP devices
description = 'Found ' + sysdesc + 'on interface
                                                        attached
' + str(interface)
                               string = 'Applying
                                                        Set description string of
WLAN access point macro to an interface - '+
                                                        discovered device and port
str(interface)
                                                        Log INFO level messages
                          logger.info(description)
                               logger.info(string)
                               macroname =
dept['wlanap']
                               write('\r')
                               read(configPrompt)
                               write('configure
terminal\r')
                               read(configPrompt)
                               write('interface ' +
macroint+'\r')
                               read(configPrompt)
                               write(macroname
+'\r')
```

```
output =
read(configPrompt)
                              write('end\r')
                              read(configPrompt)
                              for error in
macroerr:
                                   if error in
output:
                                       er = 'ERROR-
                                                       Display error if failure
Fail to apply macro: '+ str(output)
                                                       occurs
logger.error(er)
                                       ret = False
    except Exception as err:
        er = 'ERROR-apply macro:' + str(err)
        logger.error(er)
        return False
    return ret
def getnewint(session, iflist1, iflist2):
    ret =[]
    for inter in iflist2:
        if inter not in iflist1:
             ret.append(inter)
    return ret
#
if __name__ == '__main__':
                                                       Start of the main function
    #start test execution
    #configure logging
    logger = logging.getLogger('Autoport')
                                                       The autoport.log file is
    logger.setLevel(logging.INFO)
                                                       created on the switch in the
    ch = logging.StreamHandler()
                                                       user-apps directory. Script
    ch.setLevel(logging.INFO)
                                                       output is exported here for
    formatter = logging.Formatter('%(asctime)s -
                                                       verification and debugging
%(name)s - %(levelname)s - %(message)s')
    ch.setFormatter(formatter)
    logger.addHandler(ch)
    fh =
logging.FileHandler('/mnt/fastpath/user-
apps/autoport.log')
    fh.setLevel(logging.INFO)
    fh.setFormatter(formatter)
    logger.addHandler(fh)
    #
    logger.info('Application AutoportMacro is
started')
    #get parameters from param file
                                                       Python script reads .prm file
    if readparams('/mnt/fastpath/user-
                                                       for instructions
apps/autoport.prm'):
```

```
logger.info('Readparameters is
complete')
    else:
        sys.exit(1)
    #wait for 60 sec to set port properties
    logger.info('Wait for 60 seconds to comeup
the ports')
    time.sleep(60)
    #telnet to the switch
                                                     Telnet to the switch
    logger.info('Telnet to the switch')
    spawn id = logintelnet(params.host ,
params.username_, params.password_)
    if spawn_id is False:
        logger.info('Fail to open telnet session
to the switch')
        sys.exit(2)
    #Configure lldp timers
                                                     Configure the LLDP timers
    logger.info('configure lldp interval and
hold timers')
    lldptimers = setlldptimers(spawn_id,
params.interval_, params.hold_)
    if lldptimers is False:
        logger.info('Fail to configure lldp
interval and hold timers')
        sys.exit(2)
    #start iterations
    iteration = 1
    while True:
        #Get lldp interface information
                                                     Poll for LLDP information
        lldpint = getlldpifname(spawn_id)
                                                     on the interface
        if lldpint is False:
             logger.info('Fail to get lldp
interface list. try after 60 sec')
            time.sleep(60)
            lldpint = getlldpifname(spawn_id)
            if lldpint is False:
                 logger.info('Fail to get lldp
interface list on the switch')
                 logger.removeHandler(ch)
                 logger.removeHandler(fh)
                 sys.exit(1)
        #Get lldp remote-device details for each
lldp enabled interface
                                                     Gather LLDP information
        lldpdata = getlldpdetails(spawn_id,
                                                     from discovered devices
lldpint)
        if lldpdata is False:
             logger.info('Fail to get lldp
remote-device details')
        if iteration == 1:
             #Apply macro
            lldp = lldpint
```

```
applymacro(spawn_id, lldpdata)
        else:
                                                        Check if new or existing
             #Compare lldp data with previous
                                                        device
lldp data
             addint = getnewint(spawn_id, lldp,
lldpint)
             if addint != []:
                 data = getlldpdetails(spawn_id,
addint)
                 applymacro(spawn_id, data)
                                                        Apply macros to interfaces
             else:
                                                        of newly discovered
                 pass
                                                        devices
        lldp = lldpint
         iteration += 1
        time.sleep(params.pollinter_)
```

3.2 PRM (parameter) file: autoport.prm

A PRM file will be used by the Python script for input data so the script itself will rarely need modifications. This plain-text file uses a key-value structure to quickly allow programmers to add, modify, and remove the various devices and their settings.

For Auto Port Profiling, the PRM file *autoport.prm* will need to be created by the user. The information in this file will be used by the Python script, autoport.py, created above in section 3. Create a PRM file from your Windows or Linux desktop with a scripting editor that uses plain text character encoding (UTF-8 or ASCII).

When defining variables in the autoport.prm, the names of the parameters which are specific to the switch should contain a trailing underscore (i.e. host_, username_, password_). Alternatively, the parameters which are used to define departments and/or VLANs should not contain any underscores (i.e. eng, hr, fin).

autoport.prm example	description	
<pre>#switch login parameters host_ = '100.67.182.40' username = 'admin'</pre>	Provide the login credentials for your switch	
<pre>password_ = 'P@ssw0rd' pollinter_ = 60 #lldp parameters interval_ = 15 hold_ = 2 #Macro parameters</pre>	Provide polling for new devices, in seconds; interval time to advertise notifications/tlvs; hold timer to decide if the lldp neighbor is live	
<pre>eng = {'intrange':'Gil/0/1- Gil/0/6','telephone':'macro apply profile-phone \$general_vlan 100 \$voice_vlan 110',\</pre>	For Engineering, create specific range of ports to apply the appropriate "engineering VLANs" and device macros each time a device is attached	

```
For Finance, create specific
fin = { 'intrange': 'Gi1/0/7 Gi1/0/8 Gi1/0/9
                                                          range of ports to apply the
Gi1/0/10 Gi1/0/11 Gi1/0/12', 'telephone': 'macro
                                                          appropriate "finance
apply profile-phone $general_vlan 200
                                                          VLANs" and device macros
$voice_vlan 210',\
                                                          each time a device is
        'wlanap': 'macro apply profile-wireless
                                                          attached
$native_vlan 220',\
        'switch': 'macro apply profile-switch
$native_vlan 230'}
hr = { 'intrange ': 'Gi1/0/13 Gi1/0/14-
                                                          For the HR, create specific
Gi1/0/18', 'telephone': 'macro apply profile-phone
                                                          range of ports to apply the
$general_vlan 300 $voice_vlan 310',\
                                                          appropriate "HR VLANs"
                                                          and device macros each
        'wlanap': 'macro apply profile-wireless
                                                          time a device is attached
$native_vlan 320',\
        'switch': 'macro apply profile-switch
$native_vlan 330'}
```

When specifying interfaces to be assigned to each group, the programmer has the option of defining a range as shown for Engineering (i.e. Gi1/0/1-Gi1/0/6), a list as shown for Finance (i.e. 'Gi1/0/7 Gi1/0/8 Gi1/0/9 Gi1/0/10 Gi1/0/11 Gi1/0/12, each separated by a single space), or a combination of both a range and a list as shown for HR (i.e. Gi1/0/13 Gi1/0/14-Gi1/0/18).

Note: The PRM example assumes you already have the VLANs created at the global level. As with other commands, it is optional to automate the creation of VLANs within the script.

Applying and executing the Python script (with PRM file)

This chapter provides instructions on how to transfer the Python script and parameter file to the switch and run the script.

Note: Complete instructions on how to transfer, enable, run, disable, and remove a script to and from a switch are available in the deployment guide, *Python Scripting for Dell EMC Networking N-Series*.

Enter the commands below from the switch command line to copy the PRM file to the N-Series switch:

commands to add or update the parameter (.prm) file	description		
console#copy source-url/autoport.prm application autoport.prm	copy the parameter file from the source to the switch (use the application option)		
console# dir user-apps	confirm the parameter file was copied to the user-apps directory		

Enter the commands below from the switch to apply and execute the Python script on the N-Series switch:

commands to apply the Python script	description		
console#copy <i>source-url/autoport.tgz</i> application <i>autoport.tgz</i>	copy the Python script (compressed with .tgz or .tar.gz) from the source to the switch (use the application option)		
console# dir user-apps	confirm the Python script was copied to the user-apps directory		
<pre>console(config)#application install autoport.py auto-restart</pre>	configuration mode command loads script into switch memory. This does not start the script, but enables it to be started.		
console# show application	verify script is loaded into memory. Scripts listed in the show applications command also have an entry in the <i>running-configuration.</i>		
console#application start autoport.py	execute the Python script		
console# show process app-resource-list	autoport.py shows up in list when running		

Note: Be sure to save the *running-configuration* to the *startup-configuration* if the script needs to run after a switch reload.

4

4.1 Validating script behavior

Follow the steps below to verify proper execution of the Auto Port Profile macro script. You need at least one of each type of device you wish to support on hand to fully test the script. Confirm a macro's ability to properly configure various switch ports with these steps.

- 1. With the autoport.py script running, use a network cable to connect one of the encoded device types that was programmed to be supported (IP phone, Wireless AP, switch, etc.) to a switch port.
- 2. Allow the switch 60 seconds (configurable in .prm file) to poll for LLDP information before proceeding to the next step. Perform the next step from the switch command line.
- 3. If a global macro was used, perform a **show running configuration** command to see changes that were made to the global configuration.
- 4. If an interface macro was used, perform a **show running-configuration interface** command to see changes that were made to the interface configuration.

For example, before connecting an IP phone to interface gigabitethernet 1/0/1, the show command displayed the following configuration for that port.

console# show running-configuration interface gigabitethernet 1/0/1

<no output>

After connecting the IP phone to interface gigabitethernet 1/0/1, the configuration for that port was updated to provide support for the IP phone.

```
console # show running-configuration interface gigabitethernet 1/0/1
```

```
spanning-tree portfast
switchport mode general
switchport general pvid 10
switchport general allowed vlan add 10
switchport general allowed vlan add 20 tagged
switchport general allowed vlan remove 1
switchport port-security
switchport port-security
switchport port-security dynamic 2
voice vlan 20
macro description profile-phone
```

You also receive messages upon plugging supported devices into the switch. The first message states the device found and the port in which it was found. For example, attaching an N3132PX-ON switch into port Gi/1/0/12 displays the following:

2017-05-03 19:12:06,665 - Autoport - INFO - Found Dell Networking N3132PX-ON, 6.3.6.2, Linux 3.6.5-4cc3c5a9on interface Gi1/0/12

The second message states the macro that was applied to the port.

```
2017-05-03 19:12:06,666 - Autoport - INFO - Applying switch macro to an interface - Gi1/0/12
```

Disabling the script

Use the **application stop** command to stop the running script. This command does not remove the script from switch memory. The script resides in memory to be run again at a later time.

```
console#application stop autoport.py
```

Note: Output of a script goes only to the switch console screen. It may be easier to SSH/Telnet into the switch to stop a running script if the console is continuously scrolling.

You may also remove the script completely from the switch if the script is never to be used again. Use the **erase** command to remove the Python script from the switch.

console#erase application autoport.py

To remove the corresponding PRM input file, the command is

console#erase application autoport.prm

Use the **dir user-apps** command to verify that the script and parameter files have been removed from the user-apps directory.

console#dir user-apps

All Auto Port Profile macro automation has now been removed from the switch. Consult the <u>Python Scripting</u> <u>for Dell EMC Networking N-Series</u> guide for more information including other ways to start and stop Python scripts on the Dell EMC Networking N-Series switch.

Auto Port Profile script flowchart

This flowchart illustrates the processes used in deploying the autoport.py script on a switch. It shows creating, enabling, executing, disabling, and removing the script and actions taken by a script to configure a switch.



Figure 4 Common flows of an autoport.py script on Dell EMC Networking N-Series switches

Troubleshooting

7

Table 2 provides tips on how to help alleviate problems that may be encountered when working with various concepts and features covered in this document.

Table 2Troubleshooting

Problem	Possible Solution(s)
error "ImportError: no module" is received when importing a module into Python	The module you are trying to use is not available. Double-check the spelling of the module.
	It is possible that the module is valid for Python but not supported in the Dell EMC Networking N-Series switch. A complete list of supported modules for N-Series can be found in the "Python Scripting for Dell EMC
	Networking N-Series" deployment guide.
Error "execl: Exec format error" when running the "application start" command	Make sure both the compressed file (.tar.gz or .tgz) and the uncompressed file permissions are set to "execute" before copying the file onto the switch.
	Make sure the script is created and saved with a scripting editor that uses plain text character encoding (UTF-8 or ASCII). This ensures that no special (hidden) characters are embedded within the file preventing it from executing properly. Common text editors such as those used for word processing typically add special characters that restrict scripts from properly executing.
Error when attempting to start script using the "application start" command	Check to make sure the first line in the script is #!/user/bin/env python.
No output on the screen	If after starting the application script, expected output does not display in the CLI session, be sure to view the serial console for output and not an SSH or Telnet session. Python scripts only send output to the serial console.
	process app-resource-list" command.
Script files are missing from the <i>user-apps</i> directory or when typing "show application files," even though the TFTP copy was successful	Check to see if the script filename has exceeded 16 characters (including extensions). There is a limitation of 16 characters for Python script filenames. The compressed file (with a .tgz or .tar.gz extension) also has this limitation.

"tar: no gzip magic" message is seen while copying the compressed file to the switch or	The method used to compress the file is not acceptable, and the switch is not able to unpack it. Be sure to compress the script into a gzipped tar archive, with either a .tgz or .tar.gz extension. Refer to the " <u>Python Scripting</u> <u>for Dell EMC Networking N-Series</u> " deployment guide for more information.
"Unable to unpack archive" message is seen while copying the compressed file to the switch	To verify whether or not the file was properly decompressed after copying to the switch, run the "show application files" command. Any script files that still show a compress extension (e.gtgz or .tar.gz) were not properly compressed and therefore could not be decompressed. Instructions on proper compression of a file can be found in the " <u>Python Scripting for Dell EMC</u> <u>Networking N-Series</u> " deployment guide.
	Note : The switch unpacks the file during copying and strips any "compress" extensions off of the script file.
Script is not running properly using the "start-on-boot" parameter	The script may be starting too soon, not allowing for the network to be fully discovered by the switch.
For example, the script is not able to contact the TFTP/FTP server or Telnet outside of itself in the first few seconds after a reload, when using "start-on-boot" to initiate the script	After a switch reload, ports need time to initiate and connect to the network. Protocols like spanning tree, DHCP, and LLDP require a short period of time to discover the network. Stacked switches can take additional time in completing a discovery.
	Note: The Auto Port Profile macro (autoport.py) does not work on stacked switches.
	Scripts should be written to allow time for the switch ports to be fully functional. This can be done in multiple ways. Below are two examples.
	1. In the beginning of the script, include a "ping" loop to the desired remote server (e.g. TFTP server) and exit the loop once the destination is reachable. This is generally the recommended method since it allows the script to initiate and complete in the most efficient manner. It also requires the least amount of debugging and maintenance.
	2. In the beginning of the script, import the <i>time</i> Python module and use time.sleep() to hard-code a delay. This is less efficient than method 1 above, since it is difficult to determine how long of a delay is needed. Selecting a duration that is too long adds unnecessary delays in completing the script. Any duration selected today may need to be changed at a later date as other influences change on the network, switch or switch stack.

Device is not detected when plugged into the switch	Check to make sure the latest firmwares are applied on both the device and the switch.		
or	Make sure an appropriate default gateway is set on the switch.		
Port is not automatically configured as expected	Check to make sure all required licenses have been purchased and applied to the product. This is often the case when using a controller device on the same network that is used to communicate with the end device (e.g. Controllers for Wireless Access Points or IP cameras)		
	Confirm that any controller required on the network is accessible to the end device being plugged in (e.g. Network Controller for a Wireless Access Point).		
	Check that the expected LLDP packet information is present in the show lldp command. If not, confirm that the LLDP and TLVs are enabled on the remote device. These protocols are enabled by default on some devices but must be enabled manually on others. The Dell EMC 55xx switch is one example where the LLDP and TLVs must be manually enabled. The show lldp command used for gathering LLDP device information for creating the example script in this guide is show lldp remote- device detail gigabitethernet x/y/z.		
	Perform a show running-config to verify the comment "macro description profile-xxxx" is shown on all interface configurations where a macro was used.		
	If the device is a PoE powered device (PD), make sure it has been given enough time to boot up and to start passing LLDP traffic.		
	Check the log file in user-apps directory called autoport.log for more information.		
Error <188> Apr 29 23:11:28 Autoport-1 POE[PoE Req]: pc_poe_pwrdsne.c(4333) 562 %% Please configure Power Managementmode to Class Based for 802 3at devices	This is a notification/error for 802.3at devices. While devices may work while getting this error, it is recommended to set the following power options from global and interface (single or range) configuration modes:		
	console(config)#power inline management dynamic		
	<pre>console(config)#power inline detection dot3at+legacy</pre>		
	<pre>console(config-if-Gin/n/n)#power inline auto</pre>		

8 Best practices and tips

This chapter provides several best practices and tips for planning, creating, testing, deploying and maintaining scripts. Additional tips for scripting can be found in the *Python Scripting for Dell EMC Networking N-Series* deployment guide.

8.1 Planning and creating scripts

Before automating a system, it is best to first solve most issues found in the manual process. Dell EMC recommends selecting and testing the proper CLI macros for the job prior to using in a script and implementing on a large scale. See <u>Chapter 2: Understanding CLI macros</u> for more information.

The example script in this document uses the LLDP protocol to identify the various devices that may be attaching to the Dell N-Series switch. Use switch CLI commands like **show IIdp statistics all, show IIdp remote-device** and **show IIdp med remote-device** to identify which LLDP parameters are common to the device type you wish to automate. For example, plugging in one or more wireless APs and running the command **show IIdp remote-device detail gigabitethernet** *x***/***y/z* on the corresponding interfaces shows things like system name, description, capabilities supported, and capabilities enabled. The programmer must then choose the field they want to use to identify the device. The example script in this guide used the "System Capabilities Supported" information. This field was chosen after discovering that twelve out of twelve different AP models attached and tested provided the same information of "bridge, WLAN access point." This was used in the script to identify when an AP was attaching to the switch and subsequent application of the profile-wireless macro. See *Appendix B Device identification using LLDP* for more examples of where to look for LLDP information.

To show only commands in the running-configuration that contain LLDP statements, use the command **show running config all | include lldp**.

8.2 **Testing scripts**

Administrators can test Python scripts without having to compress and then copy the compressed Python script to the switch each time between edits. The recommended method is to use a Linux system to run the Python scripts while establishing a telnet connection to the switch under test. For instance, Dell EMC labs tested the autoport.py script on an N-Series several times from a remote Ubuntu system until the script was fully validated and working. Save valuable time by doing this prior to performing the **tftp copy** onto the switch. This saves valuable time, drastically cutting down on compression (tar.gz and tgz) and copying (tftp) tasks between debugging sessions.

Dell EMC validated the script using Ubuntu v. 14.04 with Python v. 2.7.6 installed (default). As written, this script requires no changes since the "hostname = 'xx.xx.xx'" line uses the actual OOB IP address of the switch. The loopback IP address would also work but only after being copied to the switch. If using the loopback address in the script, you must temporarily changed to the OOB/ management IP address. This allows remote testing to access the switch over the network.

From the Ubuntu terminal command line, go to the folder where the script resides, or set the path accordingly, in order to execute the script. Run the script by typing **python** <**script.py>** and **Enter**. The script runs just as if running it directly from the switch.

Note: Ubuntu is only one example of how to run Python scripts. Alternatives validated by Dell EMC include the use of the Python IDLE command line on Windows 10 to run the script, and directly from the Windows built-in command prompt with Python installed.

8.3 Deploying and maintaining scripts

Python scripting output is displayed from the console. For a single switch, use the console cable that comes with the Dell EMC Networking N-Series switch to view the console output. This is the preferred method for those situations where there are only a few switches involved. See the User Guide for your switch for more information on how to use the console port.

A *console switch* may also be used to allow the administrator to view several switches' console outputs from a single management station. This is usually helpful when there are several switches requiring the administrator to regularly test or manage Python scripts. See the <u>Python Scripting for Dell EMC Networking</u> <u>N-Series</u> deployment guide for an example network topology that uses a console switch to manage the network.

Command quick reference

Table 3 shows the complete list of N-Series switch commands referenced in this document in the order they were used, along with a brief description. This table can be helpful to quickly recall commands for those users already familiar with Auto Port Profile. Duplicate commands in the guide are represented only once in the list.

Table 3	Commands	used in	this	quide
	001111101100			galao

Command	Description	
show parser macro brief	Lists all macros available	
show parser macro	Provides details of available macros	
show running-configuration interface gi 1/0/1	Displays the port configuration	
<pre>macro apply profile-phone \$general_vlan 10 \$voice_vlan 20</pre>	Applies the specified macro to a port	
macro name profile-shaper	Creates a new macro named profile-shaper	
macro apply profile-shaper \$vlanList 5-500 \$rate 1000 \$description uplink1	Applies the profile-shaper custom macro to a port	
show parser macro name profile-shaper	Provides details of custom macro	
copy running-configuration startup-configuration	Saves the configuration to the startup-config	
copy tftp:source-url/autoport.prm autoport.prm	Copies parameter file to the switch	
dir user-apps	Shows Python and parameter files on switch	
<pre>copy tftp:source-url/autoport.tgz application autoport.tgz</pre>	Copies the tarred Python script to the switch	
application install autoport.py auto-restart	Loads script into switch memory	
show application	Verifies script is loaded into memory	
application start autoport.py	Executes the Auto Port Profile Python script	
show process app-resource-list	Scripts will show up in list when running	
show running-configuration	Show the running configuration	
application stop autoport.py	Stops the running script, leaving it on switch	
erase application autoport.py	Removes the script from the switch	
erase application autoport.prm	Removes the parameter file from the switch	
show lldp remote-device detail gigabitethernet $x/y/z$	Shows LLDP information for attacheddevices	
show running config all include lldp	Shows LLDP commands in the switch config	
power inline auto power inline detection dot3at+legacy	For 802.3at device compatibility	
power inline management dynamic	For 802.3at device compatibility	
power inline detection dot3at+legacy	For 802.3at device compatibility	

9

A Glossary of Terms

console – the interface that uses the serial port of a switch for management purposes.

console switch – a device that allows management of several switches from a single management station, via the console port on each switch.

CLI (command line interface) – a text-based interface for issuing commands to a switch (typically uses Telnet, SSH, or a serial console).

LLDP (Link Layer Discovery Protocol) – a layer 2 protocol used by network devices to identify themselves and their capabilities to neighbor devices on the network.

macro – a file containing several commands that allows the user to execute them simply by entering a single command. Macros are typically used to automate tasks that need to be repeated regularly or often.

module (Python) – a pre-written Python script (from the Python library) available for programmers to import and use in their own programs to save time.

OOB port – the Out-of-Band port, the port used to connect devices to the OOB management network.

Out-of-band – a separate management network that takes management traffic off of the production network.

package – similar to a module and often used interchangeably, part of the Python library of pre-written code for users.

PoE – Power over Ethernet; the concept of powering Ethernet networked devices over the same copper Cat cable that is carrying data.

PD – powered device; usually an end device, powered by PoE.

prm file – parameter file used as an input file for a Python script.

Python – a popular, high-level programming language with a vast standard library.

serial port - a serial interface through which users may communicate with the switch requiring a single cable, a "console cable," between the switch and a computer.

SSH (Secure Shell) – a network protocol that allows users to securely log into a switch or other system on the same network.

tarball – a single compressed file that contains one or more other files to be transported as one, unpacked, then used in another area or application.

Telnet - a network protocol that allows users to log into a switch's command line interface. Telnet is less secure than SSH.

TFTP – Trivial File Transfer Protocol, a common protocol used to transfer files between local and remote hosts.

VLAN (virtual local area network, or virtual LAN) - logical subgroups that are partitioned off a physical network in order to create separate broadcast domains.

Β Device identification using LLDP

LLDP is a layer 2, vendor-neutral protocol used by network devices to identify themselves and their capabilities to neighboring devices on the network. Identifying information must be obtained through LLDP in order for the Auto Port Profile script to work. Any number of fields resulting from a show 11dp command may be used to identify devices. The autoport.py script in this guide used the "System Capabilities Supported" information to identify Wireless APs, IP phones, and network switches. Though not a comprehensive list, Table 4 shows some of the more standard LLDP fields that may be used. It is up to the Python script developer to determine which field(s) are best used for their purpose.

Table 4 Example LLDP II	Table 4 Example LLDP fields used to identify equipment				
LLDP field	Examples of field content	Example equipment identified			
Model Name	CP-7941G, CP-8961, CP9971	IP phones			
Media Policy Application Type	Voice, Voice/Voice Signaling	IP phones			
System Name	MAC addresses, hostnames, camera	Wireless APs, IP phones, Cameras			
System Description	Axis, Snome, ArubaOS, Polycom	Wireless APs, Cameras			
System Capabilities Supported	Telephone, WLAN, router	Network Switches, IP phones, APs			
System Capabilities Enabled	Bridge, telephone, WLAN, router	Network Switches, IP phones, APs			

Table 4	Example L	LDP fields	used to	identify	equipment
---------	-----------	------------	---------	----------	-----------

Table 5 shows example devices readily identified by the System Capabilities Supported field upon running the show lldp remote-device detail gigabitethernet x/y/z command. The first column shows the device being attached. The second column shows identifying information that can be used by the script to distinguish the device type being attached. Many of these devices were used in validating the example script in this guide.

Device attached to switch port	System Capabilities Supported
Aastra IP Phone 6721	telephone
Cisco IP Phone 7941	telephone
Cisco IP Phone 8961	bridge, telephone
Cisco IP Phone 9971	bridge, telephone
Polycom Phone VVX500	bridge, telephone
Snom IP Phone	bridge, telephone
Ruckus ZoneFlex R510	bridge, WLAN access point, router
Ruckus ZoneFlex R710	bridge, WLAN access point, router
Aerohive AP130	bridge, WLAN access point
Aerohive HiveAP 141	bridge, WLAN access point
Aerohive AP230	bridge, WLAN access point
Dell AP105	bridge, WLAN access point
Dell AP135	bridge, WLAN access point
Dell AP-175P	bridge, WLAN access point
Dell W-AP205	bridge, WLAN access point
Dell W-IAP93	bridge, WLAN access point
Dell W-IAP105	bridge, WLAN access point
Dell W-IAP109	bridge, WLAN access point
Dell W-IAP204	bridge, WLAN access point

Table 5 Example equipment identified using System Capabilities Supported

Dell W-IAP205	bridge, WLAN access point
Dell W-IAP277	bridge, WLAN access point
Dell W-IAP314	bridge, WLAN access point
Dell W-IAP335	bridge, WLAN access point
Axis IP Camera	station only
Sony IP Camera	station only
Dell PowerConnect 5524	bridge, router
Dell EMC N2048 switch	bridge, router
Dell EMC N3132PX-ON	bridge, router
Dell EMC N2128PX-ON	bridge, router
Dell EMC X1008	bridge
Dell W-7010 Wireless Controller	bridge, router
Dell S3048-ON	repeater, bridge, router

Additional Resources

С

Support.dell.com is focused on meeting your needs with proven services and support.

DellTechCenter.com is an IT Community where you can connect with Dell EMC customers and Dell EMC employees to share knowledge, best practices and information about Dell EMC products and installations.

Referenced or recommended Dell EMC publications:

- Dell EMC Networking Support
 http://www.dell.com/support
- Dell EMC TechCenter (community forums and blogs for Dell EMC customers)
 - http://delltechcenter.com
 - Python Scripting for Dell EMC Networking N-Series

 http://en.community.dell.com/techcenter/networking/m/networking_files/20442227/download
- Dell EMC Networking Whitepapers
 http://en.community.dell.com/techcenter/networking/p/guides
- Dell EMC Networking N15xx User Guides and Firmware downloads
 - http://www.dell.com/support/home/us/en/19/product-support/product/networking-n1500-series
- Dell EMC Networking N2xxx User Guides and Firmware downloads
 - <u>http://www.dell.com/support/home/us/en/19/product-support/product/networking-n2000-series</u>
- Dell EMC Networking N3xxx User Guides and Firmware downloads
 - http://www.dell.com/support/home/us/en/19/product-support/product/networking-n3000-series
- Dell EMC Networking N4xxx User Guides and Firmware downloads
 - http://www.dell.com/support/home/us/en/19/product-support/product/networking-n4000-series

D Support and Feedback

Contacting Technical Support

Support Contact Information

Web: <u>http://Support.Dell.com/</u> Telephone: USA: 1-800-945-3355

Feedback for this document

We encourage readers of this publication to provide feedback on the quality and usefulness of this deployment guide by sending an email to <u>Dell_Networking_Solutions@Dell.com</u>

About Dell EMC

Dell EMC is a worldwide leader in data center and campus solutions, which includes the manufacturing and distribution of servers, network switches, storage devices, personal computers, and related hardware and software. For more information on these and other products, please visit the Dell EMC website at http://www.dell.com.