

Dell[™] High Availability Solutions Guide for Microsoft[®] Hyper-V[™] R2

A Dell Technical White Paper



THIS WHITE PAPER IS FOR INFORMATIONAL PURPOSES ONLY, AND MAY CONTAIN TYPOGRAPHICAL ERRORS AND TECHNICAL INACCURACIES. THE CONTENT IS PROVIDED AS IS, WITHOUT EXPRESS OR IMPLIED WARRANTIES OF ANY KIND.

© 2011 Dell Inc. All rights reserved. Reproduction of this material in any manner whatsoever without the express written permission of Dell Inc. is strictly forbidden. For more information, contact Dell.

Dell, the *DELL* logo, and the *DELL* badge, *EqualLogic*, *Compellent* and *PowerVault* are trademarks of Dell Inc. *Microsoft*, *Windows*, *Hyper-V*, and *Windows Server* are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

October 2011

Contents

Getting Started with High Availability	4
New Features in Windows Server 2008 R2	4
Cluster Shared Volume	4
Live Migration	5
Clustering Implementations for High Availability	5
Hyper-V Guest Clustering	5
Hyper-V Host Clustering	7
Planned and Unplanned Failover (Host Cluster Model Only)	8
Planned Failover Using Live Migration	8
Cluster Shared Volume	8
Planned Failover Using Quick Migration	10
Processor Compatibility Requirements	11
Unplanned Failover	12
Comparison of Guest and Host Clustering	14
Designing for High Availability	15
Node and Disk Majority versus Node Majority Cluster Configuration	15
Storage Configuration	16
Sharing a LUN for Multiple HA VMs	16
Storage Options for Hyper-V Host Clustering	17
Network Configuration	18
Cluster Network Types	18
Best Practice Recommendations	20
Recommended Configurations	20
Design for iSCSI-Based Configurations	21
Design for Fiber Channel Configurations	22
Design for Direct-Attach SAS Configurations	23
Implementing High Availability in Hyper-V	24
Implementing Hyper-V Host Clusters	24
Preparing the Systems	24
Configure the Failover Clustering Feature and Hyper-V Role	25
Creating Virtual Machines That Will be HA VMs	25
Creating Virtual Machines that will be HA VMs using CSV	27
Enabling VMs as HA VMs	28

Migrating HA VMs across Hosts in the Cluster	28
Hyper-V Host Clusters on Server Core	29
Setting up the Server Core System for Hyper-V and Failover Clustering	29
Setting up Remote Management to Server Core	29
Remote Management from Windows Server 2008 R2 Full Install	30
Remote Management from Windows Vista	30
Administering High Availability for Hyper-V	30
Changing the Configuration of HA VMs	30
For Configuring Changes that Impact the VM's HW Profile	30
For Configuring Changes that DO NOT Impact the VM's HW Profile	31
Adding Passthrough Disks to HA VMs	31
Sharing LUNs Between HA VMs	32
HA VM Resource Group Names	32
Cluster Resource Group for HA VMs Reported as "Partially Online"	32
Configuring Rules for Associating Hosts to HA VMs	33
Setting Host Preferences for HA VMs	33
Blocking HA VMs from Running on Certain Hosts	33
Converting an Existing Non-HA VM to a HA VM	33
Converting an HA VM to a Non-HA VM	34
Using SMB/CIFS Shares in Hyper-V	35
Using Mount Points in Hyper-V	36
Hyper-V Host Clustering Data Template	37
References	39
Glossary	40

Tables

Table 1.	Comparison of Guest and Host Clustering	14
Table 2.	Comparison of Node Majority versus Node and Disk Majority	16
Table 3.	Determining if a LUN Can Be Shared	17
Table 4.	Storage Types For Hyper-V Clustering	18
Table 5.	Dedicated Network Ports for Hyper-V Host Cluster Nodes	19
Table 6.	iSCSI-Based Configuration Network Requirements	21
Table 7.	Fiber Channel-Based Configuration Network Requirements	22
Table 8.	Direct-Attach SAS-Based Configuration Network Requirements	23
Table 9.	Hyper-V Host Cluster Summary	37

Table 10.	Hyper-V Host Cluster Nodes	37
Table 11.	Hyper-V Host Cluster Network	38
Table 12.	Hyper-V Host Cluster HA VM Resource Group Information.....	38

Figures

Figure 1.	Hyper-V Guest Clustering Within a Single Physical Server	5
Figure 2.	Hyper-V Guest Clustering Across Two Standalone Physical Servers	6
Figure 3.	Hyper-V Host Clustering	7
Figure 4.	Hyper-V Host Cluster With CSV Enabled Before Migration	9
Figure 5.	Hyper-V Host Cluster With CSV Enabled After Migration	9
Figure 6.	Hyper-V Host Cluster Before Migrating	10
Figure 7.	Hyper-V Host Cluster After Migrating.....	10
Figure 8.	Hyper-V Host Cluster With Both Servers Running.....	12
Figure 9.	Hyper-V Host Cluster After One Server Fails	13
Figure 10.	iSCSI-Based Hyper-V Host Cluster Configuration.....	21
Figure 11.	Fiber Channel-Based Hyper-V Host Cluster Configuration.....	22
Figure 12.	SAS-Based Hyper-V Host Cluster Configuration	23
Figure 13.	Typical VHD Configuration on Storage Disk Assigned with a Drive Letter.....	36
Figure 14.	Typical VHD Configuration on Storage Disk Configured with a Mount Point	36

Getting Started with High Availability

High Availability (HA) solutions are not new to Windows® environments. Microsoft has offered native support for HA through its Microsoft Cluster Services (MSCS) in Windows 2000, Windows Server® 2003, and Windows Server 2003 R2, and with the Windows Failover Clustering (WFC) feature in Windows Server 2008 and Windows Server 2008 R2. Failover clustering reduces the possibility that any single point of failure in your virtualization environment will cause your workloads to become unavailable. In a non-virtualized environment, HA implementation was traditionally only used for environments that were hosting critical workloads because the loss of a non-critical service hosted on any single physical server was considered acceptable.

However, in a virtualized environment in which a single physical server will host many virtual machines, the loss of that physical server will result in the loss of service of multiple workloads. To prevent this scenario, implementing HA should be a primary goal of any virtualization deployment regardless of scale or scope, especially in a production environment.

This *Dell® High Availability Solutions Guide for Microsoft Hyper-V™* white paper introduces different options to implement HA for Hyper-V environments, and provides recommendations and best practices for configuring your Hyper-V HA environments on Dell hardware.

This paper assumes that you have a basic understanding of Hyper-V, as well as the networking and storage concepts of Hyper-V. If you have not already read them, Dell strongly recommends that you review the following guides to get an in-depth understanding of Hyper-V solutions on Dell hardware:

- [Dell Solutions Overview Guide for Microsoft Hyper-V](#)
- [Dell Networking Solutions Guide for Microsoft Hyper-V](#)
- [Dell Storage Solutions Guide for Microsoft Hyper-V](#)

New Features in Windows Server 2008 R2

Windows Server 2008 R2, Hyper-V uses Cluster Shared Volume (CSV) storage to simplify and enhance multiple windows servers to access SAN storage. It also adds new features such as live migration functionality, support for adding or removing storage from a virtual machine, and enhancements to processor and networking support.

Cluster Shared Volume

Cluster Shared Volume (CSV) is available as part of the Windows Failover Clustering feature of Windows Server 2008 R2. CSV is a volume that is simultaneously available to directly read from and write to by all nodes in a Microsoft® Failover Cluster. This capability, referred to as Direct I/O, is made possible by providing a distributed access file system, which allows each node to utilize its storage interconnect—Internet SCSI (iSCSI), Fibre Channel, Serial Attached SCSI (SAS)—for communication with the volume on the shared storage array. CSVs also provides the ability for multiple virtual machines (VMs) to share a single shared storage volume while also allowing these VMs to migrate (live or quick) independently between hosts in the cluster. In the event that a node loses its path(s) to the shared storage array, CSVs provide the capability to reroute data over the network. CSV enables faster live migration and easier storage management for Hyper-V when used in a cluster configuration.

Live Migration

Live migration allows you to transparently move running virtual machines from source node of the failover cluster to the destination node in the same cluster without a dropped network connection or perceived downtime. In this case there is no transfer of disk ownership between the nodes. Live migration requires the failover clustering role to be added and configured on the servers running Hyper-V. In addition, failover clustering requires shared storage for the cluster nodes.

Clustering Implementations for High Availability


Hyper-V HA implementations can broadly be categorized into Hyper-V Guest Clustering and Hyper-V Host Clustering. The differences in the two types are based on where the clustering service is running and what the clustering service is managing.

Hyper-V Guest Clustering


In a Guest Cluster implementation, the clustering service runs on the guest operating system in the virtual machine. This type of clustering provides high availability for applications that are hosted within the virtual machines.

As illustrated in Figure 1 and Figure 2, Hyper-V Guest Clustering can be implemented with the VMs either deployed on a single physical server, or across multiple physical servers.

Figure 1. Hyper-V Guest Clustering Within a Single Physical Server



In Figure 1, virtual machines A and B are running on the same server. In this scenario, the workloads being managed by the clustering service in the guest operating systems in the VMs will not survive a physical server outage or a crash of the parent partition. If the physical server or the Windows Server 2008 R2 instance running in the parent partition fail, all of the VMs running on this system fail, causing the clustered workloads within the VMs to also fail.

Figure 2. Hyper-V Guest Clustering Across Two Standalone Physical Servers

In Figure 2, the clustered virtual machines A and B are running on different physical servers. In this scenario, the workloads being managed by the clustering software within the VMs are able to offer continued service even in the case of an unplanned physical server downtime or parent partition outage.

As in all cluster implementations, the Hyper-V Guest Cluster implementation also requires that the cluster service running in all the guest operating systems has direct access to a common shared storage. In the case of Hyper-V Guest Cluster, the only way to provision shared storage that is accessible directly by multiple VMs is by using iSCSI-based storage (Direct Attached SAS and Fiber Channel Arrays are not supported for Hyper-V Guest Clustering). With the iSCSI initiators running in the guest operating systems, Hyper-V VMs can directly talk to the iSCSI storage without going through the storage stack of the parent partition.

 **NOTE:** The [Dell Storage Solutions Guide for Microsoft Hyper-V](#) provides more detailed information on provisioning iSCSI storage disks directly to Guest operating systems.

Because configuring clustering within the guest operating systems in the VMs is no different than configuring clustering on physical servers that are not virtualized, this solutions guide does not discuss this model any further. For more information, refer to the Microsoft Failover Clustering documentation for the guest operating system.

Hyper-V Host Clustering

In this implementation, the Hyper-V Host servers are clustered by leveraging the Windows Failover Clustering features in Windows Server 2008 R2 x64 editions. Failover Clustering in Windows Server 2008 R2 is a robust and mature, third-generation clustering solution that has been significantly improved in Windows Server 2008 R2. Leveraging this Failover Clustering feature allows Hyper-V to offer HA solutions on a wide array of storage solutions including Direct-Attach SAS, iSCSI, and Fiber Channel storage arrays.

Figure 3. Hyper-V Host Clustering




Figure 3 illustrates a sample Hyper-V Host Cluster configuration with the Windows native cluster service running in the Windows Server 2008 R2 x64 parent partition. In this scenario, the Failover Clustering service in the parent partition will manage the VMs as the cluster resources. The VMs running on either of these servers can be configured as highly available and do not require clustering capabilities in the guest operating systems in the VMs. The only requirement is that all the virtual machine files are on storage accessible by all the physical servers that are part of the cluster. (For the remainder of this document, VMs managed by the cluster for high availability are referred to as HA VMs.)

Hyper-V Host Clustering is the recommended mechanism to implement HA in a Hyper-V environment. Clustering has many advantages including a wide array of configuration options, ease of management, and scalability. In addition to providing HA, this solution also supports planned downtime activities such as for physical server maintenance and enabling dynamic datacenter capabilities such as VM workload balancing.

Windows Server 2008 R2 supports a maximum of 16 physical servers in a single Failover Cluster configuration. Therefore, a single Hyper-V Host Cluster configuration can have a maximum of 16 physical servers. A maximum of 1000 virtual machines supported per single Failover Cluster configuration, and each cluster node supported no more than 384 virtual machines, see [Requirements and Limits for Virtual Machines and Hyper-V in Windows Server 2008 R2](#). Hyper-V Host Clustering may be implemented on the following editions of Windows Server 2008 R2:


- Windows Server 2008 R2 x64 Enterprise Edition
- Windows Server 2008 R2 x64 Datacenter Edition

Planned and Unplanned Failover (Host Cluster Model Only)

The Hyper-V Host Cluster model accommodates both planned and unplanned downtime. A planned downtime is when a physical server that is part of a Hyper-V Host Cluster is taken offline by the administrator for maintenance, such as a hardware upgrade or applying an OS patch. An unplanned downtime is when a physical server that is part of a Hyper-V Host Cluster becomes offline unexpectedly due to hardware failure, a parent partition crash, or other reason. Physical servers that are part of a cluster are commonly referred to as cluster nodes.

Planned Failover Using Live Migration

Live migration provides the capability to move a virtual machine (VM) from one node in Windows Server 2008 R2 failover cluster to another node without a perceived interruption in service by applications/clients connecting to the VM. Here is a high-level workflow of the VM migration process during planned failover:

 **NOTE:** On a server running Hyper-V, only one live migration either to or from the server can be in progress at a given time. You cannot use live migration to move multiple virtual machines simultaneously. Live Migration can occur between two different set of nodes in a cluster simultaneously; a cluster will support *number_of_nodes/2* simultaneous live migrations. For example, an eight node cluster can support four simultaneous live migrations, with no more than one live migration session active from every node of the cluster.

The cluster copies the initial memory state being used by the VM from the originating node to destination node (through Live Migration network)

1. Any memory pages that were changed during the copy process (dirty pages) are marked, and the pages are copied over as well. This iterative process continues until the number of pages is relatively small.
2. The VM is paused on the originating node, and the state of the VM is copied to the destination node where it is resumed.

Cluster Shared Volume

Hyper-V in Windows Server 2008 R2 has an add-on feature called Cluster Shared Volume (CSV) which increases the availability and performance of Hyper-V virtual machines with improved management. CSVs are the shared disks in Available Storage that can be accessed by all cluster nodes, using a single consistent namespace for all volumes.

When CSV is enabled in failover cluster management GUI, the following folder is created:

```
%systemroot%\ClusterStorage
```

All the CSV LUNs appear within this folder in a **volume(n)** folder. For example,

C:\ClusterStorage\Volume1.

For live migration with CSV, there is no transfer of disk ownership between the nodes. The transition is instantaneous so that a client accessing the VM does not lose the network connection.

Figure 4. Hyper-V Host Cluster With CSV Enabled Before Migration





Figure 5. Hyper-V Host Cluster With CSV Enabled After Migration



Planned Failover Using Quick Migration

To accommodate the planned downtime of a server, the administrator can choose to move all the VMs from that server to the other servers in the Hyper- V Host Cluster. Here is a high-level workflow of the VM migration process during planned failover:

1. VM in the originating node is placed in save state (the contents of memory are saved to files located on SAN storage).
2. SAN storage disk ownership is moved from the originating node to the destination node.
3. VM is started on the destination node and state is restored from SAN storage.

NOTE: The difference between Quick and Live Migration is that Quick Migration saves the VM state, moves cluster resources, and restores the VM, resulting in some system downtime.

Figure 6. Hyper-V Host Cluster Before Migrating






Figure 7. Hyper-V Host Cluster After Migrating



This save and restore operation ensures that the state of the VM is retained during the migration process. The guest operating system is unaware of this VM save and restore process, it is frozen during the migration period. Microsoft calls this capability to migrate VMs across physical servers Quick Migration.

Even though there is no loss of state or data during this process, it is not a live migration process. The guest OS and the workloads within the VM will be offline and not available to users during the migration period.

 **NOTE:** Any active connections with the guest operating system in the VMs will be lost when the VM undergoes migration. The connections have to be re-established after the migration is complete.

The offline duration period is typically between 15 seconds and a few minutes, depending mainly on the following factors:


Amount of memory used by the guest operating system: This is the most important factor because the time taken for VM migration is directly proportional to the amount of memory that is being used by the guest operating system; the more memory being used by the guest OS at the time of the migration, the longer the migration. Note that the amount of memory being used by the guest OS is not the same as the amount allocated to the virtual machine. Unless the virtual machine is running a very memory intensive workload, the memory utilized is usually much less than the memory allocated to the VM.

Speed of the storage fabric: The connection speed to the storage array is a factor because the state of the VM is transferred from the source node to the shared storage and then restored from shared storage to the destination node over the storage fabric. So, it is very important that you plan your network (in case of iSCSI) and storage deployment to ensure that there are no bottlenecks that could impact quick migration times.

Processor Compatibility Requirements

Quick Migration is a stateful migration process and so requires that the processors on the source and destination cluster nodes be compatible. Hypervisor-based virtualization software (such as Hyper-V) allows certain CPU instructions from the virtual machines to execute directly on the physical processors. Therefore, the state of a VM may have a dependency on a specific feature of the physical processor.

Processor features vary between processor vendors, processor models, and processor families. During a VM quick migration across physical servers that do not have identical processors, if the processor on the destination node does not support a feature that is leveraged by the VM in the source node, it can cause the VM state restore process to fail on the destination node.

 **NOTE:** In the scenario where the processors on the cluster nodes are not feature compatible and the VM fails to restore state on the destination node, the cluster service will attempt to restore the VM (along with the saved state) on the originating cluster node if that node is still online. However, this behavior is impacted if changes are made to the default settings for how the Failover Cluster service in Windows Server 2008 R2 manages its resources.

NOTE: If you have more than one processor family used by the nodes of your cluster, then live migration may fail with the default settings. To allow live migration to succeed, each VM must have the processor migration compatibility setting enabled. This setting can only be changed when the VM is powered off. Dell strongly recommends that all of the nodes of a Hyper-V Host Cluster configuration have identical processors.

Unplanned Failover

In the case of unplanned downtime, the nodes in the Hyper-V Host Cluster do not have the time to initiate a VM Quick Migration. Instead, the cluster service automatically restarts all the HA VMs on the other nodes of the cluster. In this unplanned failover scenario, the state of the VM is not retained and there is the possibility for data loss. To the guest operating system, this is similar to an unexpected restart of the operating system. The failover of VMs is automatically handled by the cluster service, however, and workloads running within the VMs are back online in a short period of time. Here is a high-level workflow of the unplanned failover scenario:

1. A node in the Hyper-V Host Cluster configuration fails. All states of the VM (including guest OS and workloads within the VMs) that have not been committed to SAN storage are lost.
2. Cluster service transfers ownership of SAN storage disk resources from the failed node to other nodes in the Hyper-V Host Cluster.
3. VMs are restarted on the other nodes of the Hyper-V Host Cluster.

Figure 8. Hyper-V Host Cluster With Both Servers Running







Figure 9. Hyper-V Host Cluster After One Server Fails

Unlike the case of a planned failover, where the administrator chooses a specific destination node for the VMs, in an unplanned scenario the cluster service will choose the appropriate destination server for the VMs. If a specific cluster node is found to not have sufficient resources such as CPU or memory to host the VMs, the cluster service will attempt to start the VM on another available node in the cluster.

 **NOTE:** Using the advanced features available in Windows Failover Clustering, rules may be set to restrict certain VMs to only run on certain nodes of a Hyper-V Host Cluster. For more information, refer to [Administering High Availability for Hyper-V](#).

 **NOTE:** Because the state of the VM is not retained during an unplanned failover, the processors (and their features) on the originating and destination nodes do not have to match. However, Dell strongly recommends that all servers in a Hyper-V Host Cluster have identical hardware to ensure that it also supports planned migrations.


Comparison of Guest and Host Clustering

Table 1 highlights the key differences between Hyper-V Guest Clustering and Hyper-V Host Clustering.

Table 1. Comparison of Guest and Host Clustering

Category	Hyper-V Guest Clustering	Hyper-V Host Clustering
High Availability Scope	<p>The applications running on the guest OS are the clustered entities</p> <p>HA is only for these applications and not for the VM itself</p>	<p>The virtual machines are the clustered entities</p> <p>HA is for the virtual machines as a whole (including the guest operating systems and applications within the VM)</p>
Guest OS Requirements	<p>Requires that the guest OS is supported by Hyper-V</p> <p>Requires that the guest OS has cluster software capability</p> <p>Requires that this cluster software supports iSCSI storage</p>	<p>Solution is Guest OS independent because the cluster software is running in parent partition</p>
Shared Storage Type	<p>iSCSI only</p> <p>iSCSI initiator runs in the guest OS</p>	<p>Direct Attach SAS</p> <p>iSCSI</p> <p>Fiber Channel</p> <p>SMB Share</p>
Implementation	<p>Clustering has to be configured within every VM</p> <p>May be more complex to manage if several VMs need to be made into HA VMs</p>	<p>Clustering has to be configured only in the parent partition on each host</p> <p>Implementation is independent of the number of VMs</p>
Application support	<p>Workloads within the VM must be cluster-aware</p>	<p>Workloads within VMs do not have to be cluster-aware</p>

Category	Hyper-V Guest Clustering	Hyper-V Host Clustering
Maximum number of physical servers in the cluster	No direct dependency on physical servers. Limitations may apply based on the configuration	Maximum of 16 physical servers in a single cluster configuration
Quick Migration	Not Available	Supported
Live Migration	Not Available	Supported

 **NOTE:** Based on the HA requirements, these models may be implemented in combination. However, careful planning and consideration is needed before implementation, because such an implementation will be fairly complicated to configure and manage.


Designing for High Availability

Planning and designing is a very crucial step in ensuring a highly available environment that also provides the most isolation and best performance for the HA solution. This section provides guidance for a few of the key scenarios in failover cluster configuration.

Node and Disk Majority versus Node Majority Cluster Configuration

As mentioned earlier, Hyper-V is dependent on the Failover Clustering feature to provide HA capabilities. The Failover Clustering feature in Windows Server 2008 R2 offers multiple configuration models for clustering up to 16 physical servers. The difference between the clustering models is in which of the cluster resources get to vote to decide whether or not the cluster is in a highly available state at any given time. The most common and recommended cluster configuration models are:

- Node and Disk Majority Cluster
- Node Majority Cluster

 **NOTE:** A third type called Node and File Share may be suitable for certain scenarios. However, that is beyond the scope of this document. For information on all the cluster models, please refer to Microsoft website at www.microsoft.com/windowsserver2008/failover-clusters.mspx.

Node Majority Cluster is a configuration in which only the servers that are part of the cluster can vote, and Node and Disk Majority is a configuration in which the servers and a single shared disk (SAN) resource get to vote. The choice of the cluster model is dependent on the specific requirements of the environment in which the cluster is being deployed.

Table 2. Comparison of Node Majority versus Node and Disk Majority

	Node Majority	Node and Disk Majority
Number of Nodes	Recommended for clusters with an odd number of server nodes	Recommended for clusters with an even number of server nodes
Shared Storage	Shared storage is not required for configuring the Failover Cluster Shared Storage is required for HA VMs	Minimum 500MB NTFS shared disk as Witness Disk for configuring the Failover Cluster Shared Storage is required for HA VMs
Requirement to Maintain High Availability Status	More than 50% of the nodes must be up for the cluster to be running	At least 50% of the nodes and witness disk must be available for the cluster to be running If the witness disk is not available, more than 50% of the nodes must be available for the cluster to be running

Storage Configuration

The *Dell Storage Solutions Guide for Microsoft Hyper-V* provides detailed information on the various storage configuration options in Hyper-V as well as best practices for their implementing on Dell storage arrays. This section discusses the storage considerations in a Hyper-V Host Cluster environment.

Sharing a LUN for Multiple HA VMs

A key decision point for Hyper-V Host Clusters is whether each HA VM will have its own LUN or if multiple HA VMs will share a single LUN. The main difference between these two configurations is in how they handle failovers.

The NTFS file system grants access at a LUN, or volume, level and not a file level. Consequently, when an HA VM is moved across physical servers, the ownership of all the storage LUNs that host that HA VM's files will also transfer across physical servers. This behavior impacts both planned and unplanned migrations.


Planned migration (quick migration) scenarios: if there is a need to quick migrate an HA VM independent of other HA VMs, then that HA VM cannot share any of its LUNs with other HA VMs.

Unplanned migration scenarios: this might be a factor depending on the resource requirements for all the HA VMs that share a LUN. If the cluster service is unable to successfully bring all the HA VMs (that share the single LUN) online on another node, it will retry on all other available cluster nodes. If none of the available cluster nodes can host all the HA VMs due to resource constraints, it is likely that none of the HA VMs that share the single LUN will be brought online

Table 3 lists important factors to consider if you plan to share a LUN across multiple HA VMs:

Table 3. Determining if a LUN Can Be Shared

Single LUN can be shared by multiple HA VMs	Single LUN is required per HA VM
<p>If the HA VMs are only using VHD-based virtual hard disks (and not passthrough disks)</p> <p><i>AND</i></p> <p>If it is acceptable that all HA VMs will move across hosts simultaneously in planned failover scenarios (Quick Migration)</p>	<p>If the HA VMs are using passthrough disks (and not VHD-based virtual hard disks)</p> <p><i>OR</i></p> <p>If there is a requirement to be able to migrate HA VMs one at a time in planned failover scenarios (Quick Migration)</p>

 **NOTE:** Depending on the Disk I/O in the specific configuration, sharing a single LUN across multiple HA VMs may also impact I/O performance.

Storage Options for Hyper-V Host Clustering

The type of storage that is used in a Hyper-V Host Cluster will mostly impact the design of the Hyper-V Host Cluster solution.

Storage type affects the following:

- The number of network adapters on each Hyper-V host
- The number of storage adapters on each Hyper-V Host
- Quick Migration because the VM state is saved to disk over the storage fabric

Table 4 summarizes the different types of storage that support Hyper-V Host Clustering and Hyper-V Guest Clustering. For a full list of supported storage hardware for Hyper-V, refer to the *Dell Storage Solutions Guide for Microsoft Hyper-V*.

Table 4. Storage Types For Hyper-V Clustering

Storage Type	Examples	Support for Hyper-V Host Clustering	Support for Hyper-V Guest Clustering
External Enclosures (JBODs)	PowerVault™ MD1000, PowerVault MD1120, PowerVault MD1200/MD1220	No	No
SAS Arrays	PowerVault MD3000, PowerVault MD3200/MD3220	Yes	No
iSCSI Arrays	PowerVault MD3000i, PowerVault MD3200i/MD3220i, PowerVault MD3600i/MD3620i, EqualLogic™ PS Series, Compellent Storage Center iSCSI Storage Arrays	Yes	Yes
Fiber Channel Arrays	Compellent Storage Center Fibre Channel Storage Arrays, PowerVault™ MD3600f/MD3620f	Yes	No

Network Configuration

The *Dell Networking Solutions Guide for Microsoft Hyper-V* provides detailed information on the various networking configuration options in Hyper-V as well as implementation best practices. This section discusses the networking considerations for a Hyper-V Host Cluster environment.


Cluster Network Types

In addition to storage resources, the cluster service also manages network resources on hosts that are part of the cluster. The cluster utilizes and manages these network resources based on their cluster use type as designated by the administrator when configuring the failover cluster. The cluster use type is set using the Failover Cluster Management console and selecting the specific adapters listed under **Network**. There are three cluster use types:

Internal Type: The cluster network resource is configured to allow the cluster to use the network and disallow clients to connect through the network.

Enabled Type: The cluster network resource is configured allow the cluster to use the network and also allow clients to connect through the network.


Disabled Type: The cluster network resource is configured to not allow the cluster to use this network.

 **NOTE:** These network types are defined by the Windows Failover Clustering feature in Windows Server 2008 R2 and are not related to the Hyper-V network types that are defined in the *Dell Networking Solutions Guide for Microsoft Hyper-V*.

In a recommended configuration, each node of a typical Hyper-V Host Cluster should have dedicated network ports for the following:


Table 5. Dedicated Network Ports for Hyper-V Host Cluster Nodes

Network Types	Descriptions, Configurations, and Best Practices
Network for Cluster Private	<p>One Gigabit (or Fast Ethernet) Ethernet network port for hosting the Cluster Private network.</p> <p>This network is dedicated for use by the cluster service to check the health state of each cluster node.</p> <p>Should be of cluster use type Internal.</p>
Network for Cluster Public and for Parent Partition Management	<p>One Gigabit Ethernet network port for hosting the Cluster Public network and for network access to the Windows Server 2008 R2 parent partition.</p> <p>This network will be used to:</p> <ul style="list-style-type: none"> - Manage the Hyper-V Host Cluster using the Failover Management console - Manage the Parent Partition and the Hyper-V Role <p>Should be of cluster use type Enabled.</p>
Network for Virtual Machine	<p>One or more Gigabit Ethernet network ports to host virtual machine networks.</p> <p>Should be of cluster use type Disabled to ensure isolation of the virtual machine network traffic.</p>
Network for Storage	<p>Two or more Gigabit Ethernet network ports to host iSCSI storage network (for iSCSI-based configurations).</p> <p>Should be of cluster use type Disabled to ensure isolation of the storage network traffic.</p>

 **NOTE:** Even though Failover Cluster in Windows Server 2008 R2 does not require a dedicated cluster private network because it can use the public network to monitor cluster heartbeat, Dell recommends a dedicated cluster private network to ensure the reliability of the Hyper-V Host Cluster configuration.

Best Practice Recommendations

- Static IP addresses should be used for networks — especially the Cluster Private, Cluster Public, Parent Partition, and any iSCSI Storage networks.
- Ensure that the Cluster Private network is on a separate subnet than all other networks on the Hyper-V Hosts. It is recommended that each network type in Table 5 is on a separate subnet.
- Ensure that the network configuration is completed (including assigning the appropriate subnets and static IP addresses) on every Hyper-V Host before the Hyper-V Host Cluster is configured.

 **NOTE:** This step is critical because in Windows Server 2008 R2, the Failover Cluster service automatically identifies network resources during configuration and assigns them as cluster network resources. It does this based on the subnet configurations and automatically selects at least one network adapter from each subnet. Network resources cannot be manually added or removed as a cluster resource using the Failover Cluster Management console.

- After the Failover Cluster is configured, ensure that cluster network resources have been configured as recommended in Table 5.
- When using dual-port or quad-port network adapters, host the same network types on different physical network adapters to ensure that there are redundant network paths available to accommodate a single network adapter (NIC) HW failure. For example, in a configuration with two iSCSI storage networks, instead of using two ports of the same network adapter for hosting the iSCSI network, use network ports on two separate network adapters. Follow similar best practices for Cluster Private/Public, and Virtual Machine Networks.

Recommended Configurations

As mentioned in the *Dell Solutions Overview Guide for Microsoft Hyper-V*, Dell supports Hyper-V on a very wide array of server, networking, and storage hardware. Even though the Failover Clustering feature in Windows Server 2008 does not require that the hardware in a cluster configuration be identical, Dell strongly recommends having identical hardware in any single Hyper-V Host Cluster configuration. This will ensure that there are no compatibility issues (such as processor dependencies to support Quick Migration) that could cause disruption in a production environment.

Dell offers a wide array of servers that have been specifically built with the goal of being able to host virtualized workloads. These servers offer support for large amounts of physical memory, large numbers of I/O slots for both network and storage, and a minimal power footprint. For a full list of servers that Dell recommends for virtualization, go to www.dell.com/servers.

Design for iSCSI-Based Configurations

Table 6 summarizes the recommended network requirements for an iSCSI- based configuration for a Hyper-V Host Cluster:


Table 6. iSCSI-Based Configuration Network Requirements

	Parent Partition Management & Cluster Public Network	Cluster Private Network	iSCSI Storage Network	Virtual Machine Network
Minimum Recommended Ports	1 Port	1 Port	2 Ports	2Ports*

* Scale the number of network ports based on the number of VMs and workloads. Distribute VMs across the associated virtual networks based on bandwidth requirements.

Figure 10 provides a sample configuration of the infrastructure and highlights the need for isolating the traffic for management, storage, and workloads running within the virtual machines.

Figure 10. iSCSI-Based Hyper-V Host Cluster Configuration



Design for Fiber Channel Configurations

Table 7 summarizes the recommended network requirements for a Fiber Channel- based configuration for a Hyper-V Host Cluster:


Table 7. Fiber Channel-Based Configuration Network Requirements

	Network Connections			Fiber Channel Connections
	Parent Partitions Management and Cluster Public Network	Cluster Private Network	Virtual Machine Network	Storage I/O
Minimum Recommended Ports	1 Port	1 Port	2 Ports*	2 Ports

* Scale the number of network ports based on the number of VMs and workloads. Distribute VMs across the associated virtual networks based on bandwidth requirements.

Figure 11 provides a sample configuration of the infrastructure and highlights the need for isolating the traffic for management, storage, and workloads running within the virtual machines.

Figure 11. Fiber Channel-Based Hyper-V Host Cluster Configuration



Design for Direct-Attach SAS Configurations


Table 8 summarizes the recommended network requirements for a Direct-Attach SAS-based configuration for a Hyper-V Host Cluster. It is important to note that this is only guidance, and actual deployment configuration will vary based on the existing infrastructure.


Table 8. Direct-Attach SAS-Based Configuration Network Requirements

	Network 10 Connections			SAS Connections
	Parent Partitions Management and Cluster Public Network	Cluster Private Network	Virtual Machine Network	Storage I/O
Minimum Recommended Ports	1 Port	1 Port	2 Ports*	2 Ports

* Scale the number of network ports based on the number of VMs and workloads. Distribute VMs across the associated virtual networks based on bandwidth requirements.

Figure 12 provides a sample configuration of the infrastructure and highlights the need for isolating the traffic for management, storage, and workloads running within the virtual machines.

Figure 12. SAS-Based Hyper-V Host Cluster Configuration

 **NOTE:** Even though it is possible to configure a 4-node Hyper-V Host Cluster with a Dell MD3000 SAS Storage Array, Dell recommends only a 2-node Hyper-V Host Cluster with the MD3000 SAS Array. This is to ensure that the configuration is more reliable. In a 4-node configuration, there is only one path from any one node to the storage array and that does not provide multi-path resiliency for the solution.

Implementing High Availability in Hyper-V

This section covers the procedures for implementing High Availability in Microsoft Hyper-V. This document only provides high-level guidance. For detailed instructions, please refer to *Failover Clustering in Windows Server 2008 R2* at www.microsoft.com/windowsserver2008R2/failover-clusters.mspx


Implementing Hyper-V Host Clusters

For any successful Hyper-V Host Cluster deployment, careful consideration must be given to the network and storage configurations to ensure that there are no single points of failure and to ensure that there is sufficient bandwidth for both network and storage traffic. For more information, see [Designing for High Availability](#).


This section discusses best practices for configuring a Hyper-V Host Cluster and provides high-level steps to setup a Hyper-V Host cluster. For step-by-step instructions on configuring a Hyper-V Host Cluster, refer to the Microsoft documentation *Hyper-V Step-by-Step Guide: Hyper-V and Failover Clustering* at <http://technet.microsoft.com>.


Preparing the Systems

1. Install Windows Server 2008 R2 x64 Enterprise or DataCenter Editions on your servers.
2. Make sure that all the devices on the server have the latest supported drivers from <http://support.dell.com>. Download the device drivers for Windows Server 2008 R2 x64.

 **NOTE:** Dell does not support device drivers that are downloaded from 3rd party vendors. Only use drivers from <http://support.dell.com>.


3. Configure the network connections and storage connections as planned.

 **NOTE:** Make sure that the appropriate MPIO software for the storage array has been installed on the nodes.


 **NOTE:** For Node and Disk Majority configuration of the Failover cluster, make sure that the shared LUN (minimum 500 MB) that will be used as the witness disk is configured as shared storage for all servers.

Configure the Failover Clustering Feature and Hyper-V Role

1. Install the Failover Clustering feature on all the Windows Server 2008 R2 servers that will be part of the Hyper-V Host Cluster. The feature can be enabled using the Add Feature wizard in Server Manager.
2. The Failover Clustering feature in Windows Server 2008 R2 provides a new capability that allows administrators to run a validation check on the planned configuration to identify potential issues before actually creating the failover cluster. Open the Failover Cluster console on any of the systems, run the Validate a Configuration wizard, and make sure that the configuration with all the nodes meets all the requirements for a Windows Failover Cluster.

 **NOTE:** It is strongly recommended that you address all errors and warnings reported by the validation wizard before configuring the failover cluster.

3. After all the requirements have been verified to be met, use the Failover Cluster Management console to create the failover cluster.
4. Enable the Hyper-V Role on each of the nodes of the failover cluster.

 **NOTE:** For information on enabling the Hyper-V Role, refer to the *Dell Solutions Overview Guide for Microsoft Hyper-V*.

5. Configure the Virtual Networks as planned on each Hyper-V server. Make sure that Virtual Networks are created with the exact same names on all the servers in the Hyper-V Host Cluster. For example, if any one cluster node has a virtual network called TestNetwork, all the Hyper-V hosts in the cluster should have a Virtual Network with the name TestNetwork. If not, when a HA VM fails over to a system that does not have a Virtual Network with that name, the VM will not have network connectivity. In such a scenario, the network connectivity will have to be enabled by manually configuring the virtual network for the HA VM.

Creating Virtual Machines That Will be HA VMs


This section discusses the steps used to configure a new virtual machine that will be made into an HA VM. There are different ways to create VMs for High Availability such as creating VMs on traditional volume, on a cluster-shared volume, or converting existing VMs to HA VMs (see [Converting an Existing Non-HA VM to a HA VM](#)).

Choosing the storage location that will host the virtual machine's files is the most important aspect of configuring a HA VM. As mentioned earlier, Hyper-V requires that all the files and disks (VHD or Passthrough) belonging to a HA VM are on shared storage (SAN) and are accessible to all nodes of the Hyper-V Host Cluster. To create an HA VM, the following consoles are required:


- Failover Cluster Management console (cluadmin.msc)
- Disk Management console (diskmgmt.msc)
- Storage array software console such as:
 - Dell Modular Disk Storage Manager™ for PowerVault M3xxx FC, iSCSI, and SAS storage arrays
 - Dell EqualLogic Group Manager for Dell EqualLogic arrays
 - Dell Compellent Storage Center for Dell Compellent Storage arrays

It is recommended that this process be done one VM at a time to ensure that storage disk allocations to VMs are correct. Storage configuration for a VM involves the following:


- 1 Use the SAN storage array software console to create the logical disks (LUNs) that are required for the VM. Make sure all the disks on the SAN are configured to be available to all the nodes of the cluster.

 **NOTE:** For guidance on sizing storage for virtual machines, refer to the *Dell Storage Solutions Guide for Microsoft Hyper-V*.


- 2 Use the Disk Management console on each of the server nodes to verify that the newly provisioned storage LUN is visible to all nodes.

 **NOTE:** The LUN may be in the offline state at this time on all the hosts.


- If the LUN will be used as a passthrough disk for the VM, make sure to bring the LUN Online on any one cluster node, Initialize it, and then take it Offline.
- If the LUN will host the VM's VHD file, bring the disk Online on any one cluster node, Initialize it, and Format it as NTFS.

 **NOTE:** In scenarios when the Hyper-V Host Cluster is hosting a relatively large number of VHD-based VMs, the cluster configuration may run out of drive letters in the parent partition. Hyper-V allows the use of Mount Points to host storage LUNs to work around the drive letter limitation. Refer to [Using Mount Points in Hyper-V](#) for more information.


- 3 Use the Failover Cluster Management console to add the storage LUNs as cluster resources. Confirm that the newly provisioned storage disks are listed as **Storage→Available Storage** disks and are not allocated to any specific Resource Groups.

 **NOTE:** If the storage disks are not made cluster resources at this stage, the attempt to convert a VM to an HA VM may result in an improper configuration.


- 4 When a storage disk is added as a cluster resource, the cluster will choose to bring the storage disk online on any one of the cluster nodes.
- 5 Use the Failover Cluster Management console to identify the host that owns the newly provisioned storage LUN.
- 6 Use the Hyper-V Manager console on that specific host to launch the New Virtual Machine wizard.

 **NOTE:** If the VM creation has to be done on a cluster node other than the cluster node that owns the newly provisioned storage LUN, then the storage LUN has to be moved to the node on which you are attempting to create the VM. Cluster disks in the Available Storage group can only be moved across cluster nodes using the CLI. For example, the CLI command **cluster group "Available Storage" /move** can be used to move storage disks across nodes in a two-node cluster.

- 7 In the **Specify Name and Location** screen of the New Virtual Machine wizard, select **Store the virtual machine in a different location** and specify the path to the shared storage disk that will host the virtual machine files (XML/BIN/VSV).

 **NOTE:** If the VM's boot disk will be a passthrough disk, the VM's files (XML/BIN/VSV) can either be on another shared storage LUN or a file share. See *Using SMB/CIFS Shares* in Hyper-V for more information on file shares.

- 8 At the **Connect Virtual Hard Disk** screen, choose the type of boot disk for the VM (**VHD** or **Passthrough**). For **VHD**, specify the path to the shared storage LUN. For **Passthrough** disks, select **Attach a virtual hard disk later** and attach the disk later by updating the hardware configuration of the VM.
- 9 Follow the prompts of the wizard to complete the VM configuration.
- 10 The VM is now ready to be configured as an HA VM. The administrator may choose to install the guest operating system at this time.

 **NOTE:** Before a VM can be made an HA VM, the VM's DVD Drive should be detached from physical optical drives or image files. If Integration Services were installed in the guest operating system, make sure the Integration Services CD image is detached from the VM's DVD drive. If there is a specific requirement that a VM's DVD Drive has to be in captured state, then make sure the DVD Drive is attached to an image file via a UNC path that is accessible to all nodes of the cluster.

Creating Virtual Machines That Will be HA VMs, Using CSV


1. Launch Failover Cluster Management (FCM) console by clicking **Start → Administrative Tools → FCM**.
2. In the FCM console left navigation panel, click on the cluster name.
3. In the FCM right navigation panel under **Configure** click **Enable Cluster Shared Volumes...** link.
4. If warning windows appear click **OK**. The cluster now supports CSV.
5. Use the SAN storage array software console to create the logical disks (LUNs) required for the VM. Make sure all disks on the SAN are configured to be available to all nodes of the cluster.
6. Use the **Disk Management** console on each of the server nodes to verify that the newly provisioned storage LUN is visible to all nodes.
7. Use the FCM console to add the storage LUNs as **Cluster Shared Volumes**. Confirm that the newly provisioned storage disks are listed in **Cluster Shared Volumes** and are not allocated to any specific Resource Groups.
8. When a storage disk is added as a **Cluster Shared Volumes**, the cluster will choose to bring the storage disk online on any one of the cluster nodes.
9. Use the Failover Cluster Management console to identify the host that owns the newly provisioned storage LUN.
10. Use the Hyper-V Manager or Failover Cluster Management console to launch the New Virtual Machine wizard.
11. In **Specify Name and Location** screen of the New Virtual Machine wizard, select **Store the virtual machine in a different location** and specify the path to the shared storage disk that will host the virtual machine files.
12. At the **Connect Virtual Hard Disk** screen, choose the type of boot disk for the VM (**VHD** or **Passthrough**). For **VHD**, specify the path to the CSV LUN. For **Passthrough** disks, select **Attach a virtual hard disk later** and attach the disk later by updating the hardware configuration of the VM.
13. Follow the wizard to complete the VM configuration.

The VM is now ready to be configured as an HA VM. The administrator may choose to install the guest operating system at this time.


Enabling VMs as HA VMs

Virtual machines created on a host that is a part of a Hyper-V Host Cluster do not automatically become HA VMs. The administrator has to choose to make VMs into HA VMs.

- 1 Make sure the VM that will be made an HA VM is either turned off or shut down.
- 2 Launch the Failover Cluster Management console for the system that is currently running the VM.
- 3 On the console, click **Configure a New Service or Application** to launch the High Availability Wizard.
- 4 When prompted by the wizard, choose **Virtual Machine** as the resource type and the wizard will automatically list all the VMs that meet the basic requirements for an HA VM.

 **NOTE:** If a specific VM is not listed here, make sure that VM has met all the pre-requisites for HA VMs.

- 5 Select the appropriate VM and proceed with the configuration.
- 6 Upon completion, the High Availability wizard also generates a report of the HA VM configuration that needs to be reviewed to make sure there were no issues.
- 7 The VM is now a HA VM and is ready to be turned on from either the Hyper-V Manager console or the Failover Management console.
- 8 At the end of this configuration, the Failover Cluster Management console will list the newly created Resource Group, *Virtual Machine (n)*, for the HA VM. This *Virtual Machine (n)* Resource Group will list all of the dependencies for the VM.

 **NOTE:** It is recommended that you run the dependency report for the Resource Group to confirm that the cluster service has made the right dependency mappings for the HA VM. Click on **Show Dependency Report** available in the Failover Clustering console to generate this dependency report.

- 9 It is recommended that you change the name of the resource group from *Virtual Machine (n)* to a name that more closely reflects the VM hosted within that group.

Migrating HA VMs across Hosts in the Cluster

With the VMs configured as HA VMs, they are now capable of handling both planned and unplanned downtime scenarios. For unplanned downtime, the Failover Cluster service will take care of moving the HA VMs on the other cluster nodes. For planned downtime scenarios, administrators can migrate HA VMs to the other cluster nodes.

This activity is initiated from the Failover Cluster Management console.

1. Open the Windows Failover Cluster Management console and select the appropriate **Resource Group** hosting the HA VM that needs to be migrated to another node.
2. Select **Move virtual machine(s) to another node**. The console will list the available target nodes in the Hyper-V Host Cluster.
3. Select a target node and the HA VM will be migrated to, and started on, the target node automatically.

Hyper-V Host Clusters on Server Core

Windows Server 2008 R2 offers a new installation option called Server Core that has a smaller footprint installation on the operating system. The key benefits of choosing a Server Core installation option include:

- Reducing the amount of future patching due to its reduced footprint
- Reducing attack surface because highly targeted roles such as Internet Explorer and ExplorerShell are not available in a Core environment

Server Core does not present a local GUI interface. This may introduce some new challenges because managing the system locally can only be done through a CLI. However, once a server running Server Core has been set up for remote administration, all the roles and features installed on that server (including Hyper-V and Failover Clustering) can be managed remotely using their respective GUI-based MMC consoles.

Setting up the Server Core System for Hyper-V and Failover Clustering

After the Server Core OS installation is complete, refer to the following documentation for guidance on the initial configuration tasks as well as enabling the system for complete remote management:

- Dell Solutions Overview Guide for Microsoft Hyper-V available at www.dell.com/hyper-v
- Server Core Installation Option of Windows Server 2008 R2 Step-By-Step Guide available on the Microsoft website
- Server Core Remote Management at <http://technet.microsoft.com>

To enable the Hyper-V Role and Failover Clustering features on all of the Server Core nodes, do the following:

1. Use `start /w ocsetup Microsoft-Hyper-V` to install the Hyper-V Role.
2. Use `start /w ocsetup FailoverCluster-Core` to install the Failover Clustering feature.

Refer to the following documents for configuring networking and shared storage on the Server Core systems:

- Dell Networking Solutions Guide for Microsoft Hyper-V available at www.dell.com/hyper-v.
- Dell Storage Solutions Guide for Microsoft Hyper-V available at www.dell.com/hyper-v.

Setting up Remote Management to Server Core

At a minimum, the following GUI consoles are required to remotely manage a Hyper-V Host Cluster:

- Hyper-V Manager (virtmgmt.msc)
- Failover Clustering Management (cluadmin.msc)

Both these consoles can be installed either on a Full install of Windows Server 2008 R2 (32-bit or x64) or Vista (32-bit or x64) to remotely manage Hyper-V Host Clustering on Windows Server 2008 Server Core.

Remote Management from Windows Server 2008 R2 Full Install

1. On the remote Windows Server 2008 R2 system (32-bit or x64), open Server Manager (servermanager.msc), and click **Add Features Wizard**.
2. Under Select Features, choose the following:
 - **Hyper-V Tools** under Role Administration Tools.
 - **Failover Clustering Tools** under Feature Administration Tools.
3. Proceed with the installation of the selected features.
4. After installation is complete, the Hyper-V Tools and Failover Clustering Tools consoles are available under Administrative Tools.

Remote Management from Windows Vista

1. Install the Remote Server Administration Tools (RSAT) for Windows Vista available for download from the Microsoft website.
Separate packages are available for the x86 and x64 versions of Vista. RSAT is a collection of tools that are meant to allow administrators to remotely manage the Windows server environments including Windows Server 2008 R2.
2. To install the Hyper-V Manager MMC console on Vista, download the appropriate 32-bit or x64 bit for KB952627.
3. Launch an MMC console (Start→Run and type MMC) and add the **Failover Cluster Management** and **Hyper-V Manager** snap-ins to the MMC console.

Administering High Availability for Hyper-V

This section provides guidance on the common administrative tasks used to manage HA VMs in a Hyper-V Host Cluster environment.

Changing the Configuration of HA VMs


Changes to a virtual machine configuration may or may not involve changing the hardware profile of the VM. The steps required to successfully handle a configuration change for an HA VM differ depending on whether or not the VM's hardware profile is changed.

For Configuring Changes that Impact the VM's HW Profile

These are the changes that require that the VM be in an OFF or SHUTDOWN state. Examples of this type of change include changing the number of virtual processors, changing virtual memory and adding/removing network and storage controllers.

 **NOTE:** We recommend that you use Failover Cluster Manager (FCM) instead of Hyper-V Manager when you change the setting of a clustered virtual machine.

To successfully shut down or turn off an HA VM, use the VM control actions available in the Failover Clustering MMC. Do not choose these actions from the Hyper-V Manager console because that will cause the cluster service to automatically restart the HA VM to maintain its HA status. Once the HA VM is shut down, use the Failover Clustering MMC to make a change, and then use the Failover Cluster console to start the HA VM.

 **NOTE:** If you cluster your virtual machines and then use Hyper-V Manager to change the configuration of one of those virtual machines, be sure to follow the procedure described below. Otherwise, the settings of the virtual machine might not be up-to-date in the failover cluster, which could cause problems during the next move, migration, or failover of that clustered virtual machine.

The high-level steps for making this type of configuration change for an HA VM are to refresh the configuration:

- Launch Failover Clustering MMC
- Expand Services and Applications, and then click the virtual machine for which you want to refresh the configuration.
- In the Actions pane, scroll down, click **More Actions**, and then click **Refresh virtual machine configuration**.
- Click Yes to view the details of this action.

For Configuring Changes that DO NOT Impact the VM's HW Profile

These are the changes that can be done when the VM is running. Examples of this type of change include changing the virtual network that a virtual network adapter is connected to or changing the media type that is attached to a VM's DVD drive.

The Failover Cluster Management console provides an option on the right side **Actions** panel to **refresh virtual machine configuration** for HA VMs. This option is meant to make sure that the cluster service has the most up-to-date configuration information of the HA VM. Activity such as Quick Migration of HA VMs may fail if the cluster service does not have the latest configuration information of the HA VM. The **Action** option should be chosen whenever changes are made that DO NOT impact the HA VM's HW profile.

Here are the high-level steps to make this type of configuration change for an HA VM:

- 1 Use the Hyper-V Manager console to update the HA VM's configuration information.
- 2 Use the Failover Cluster Management console to **refresh virtual machine configuration** for that specific VM.

 **NOTE:** The virtual machine will be taken offline for this action.

- 3 Validate the report generated by the wizard to confirm that the changes were successful.

Adding Passthrough Disks to HA VMs


There are two prerequisites for adding additional passthrough disks:


- The storage disk needs to already be a cluster resource as listed in **Storage→Available Storage** in the Failover Cluster console.
- The storage disk resource has to be owned by the same cluster node on which the HA VM is currently running.


Ownership of HA resources can be verified using the Failover Cluster console. Check the Resource Groups listed under **Services and Applications** to verify ownership of HA VMs and check the **Storage** section to verify ownership of disk resources. If the physical disk resource listed under **Available**


Storage and the virtual machine resource are owned by separate nodes, one of the resources needs to be moved so that they both are on the same node. If moving the VM is not a viable option, then the storage resource can be moved using the CLI. For example, `cluster group "Available Storage" /move` can be used to move storage disks across nodes.

Once the resources are owned by the same node, make sure the HA VM is either in the **Offline** or **Shutdown** state and then proceed with adding the passthrough disk to the VM by updating the VM's hardware configuration.

 **NOTE:** In order to enable the above functionality, Hyper-V allows passthrough disks that are already Available Storage cluster resources to be added to an HA VM. However, currently Hyper-V does not check if a passthrough disk is already an allocated cluster resource before allowing it to be added to an HA VM. Make sure that the correct passthrough disk is being attached.

 **NOTE:** The passthrough disk cannot be expanded dynamically.

 **NOTE:** Passthrough disks cannot be used as differencing disks.

 **NOTE:** If a LUN will be used as a passthrough disk, the capability to take snapshots of that LUN is lost.

Sharing LUNs Between HA VMs

Windows Failover Cluster allows multiple HA VMs to be hosted within the same Resource Group. This is a critical requirement for scenarios such as when multiple HA VMs have VHD files on the same storage LUN. However, careful consideration needs to be given before multiple HA VMs are hosted within a single resource group, because resource groups failover as a single entity. All of the VMs hosted on a single resource group will failover simultaneously.

Multiple VMs can share a storage LUN only if the VMs are using VHD based files rather than passthrough disks. Use the following guidelines to add a new VM to an existing HA VM group:

1. If a Resource Group has not been created already, use the procedures from "Implementing High Availability in Hyper-V" to create an HA VM, for example HA-VM1.
2. Create a new VM, for example HA-VM2, and place its VHD file on the same storage LUN that was used by HA-VM1.
3. Use the Windows Failover Cluster console to make HA-VM2 also an HA VM.
4. The failover cluster service will automatically add HA-VM2 into the existing Resource Group

HA VM Resource Group Names

By default, the cluster resource groups for HA VMs are created with generic names such as "Virtual Machine (1)" and do not inherit the names of the VMs. This is expected behavior after 951308 QFE is applied and was designed to avoid naming conflicts in resource groups as well as to accommodate the scenario of a single resource group owning multiple HA VMs. Administrators can manually change these Failover Cluster Resource Group names using the Failover Clustering MMC.

Cluster Resource Group for HA VMs Reported as "Partially Online"

When a Failover Cluster Resource Group contains more than one virtual machine and any of the virtual machines are not in the **Running** state, the status of the Resource Group will be displayed as

Partially Online. Even a Resource Group with a single HA VM may report the status of **Partially Online** when any of the dependent resources of that HA VM (such as a passthrough disk that is not hosting the boot volume of the HA VM) is in an **Offline** state.

Configuring Rules for Associating Hosts to HA VMs


Failover Clustering in Windows Server 2008 R2 allows the administrator to set rules on how cluster resources are managed among the nodes of the cluster. With Hyper-V HA VMs being managed by the Failover Cluster as a cluster resource, rules can be set for resource groups that host HA VMs as well.

 **NOTE:** Dell strongly recommends not changing the default settings except in special circumstances.

Setting Host Preferences for HA VMs

This capability in Failover Clustering allows the administrator to specify the order of preference for cluster nodes that will host a HA VM. To set host preferences at a resource group level:

1. Open the Failover Clustering console, select **Services and Applications**, and right-click the Resource Group that hosts the HA VM.
2. Select the General tab and set the order of preferences in the **Preferred Owners** list.

 **NOTE:** The Failover tab allows the administrator to specify the fallback behavior, which is based on the Preferred Owners. It is recommended that fallback be set to the default setting of Prevent Fallback in a production environment.

Blocking HA VMs from Running on Certain Hosts

This capability in Failover Clustering allows the administrator to block certain hosts from hosting a specific HA VM. To block HA VMs at a resource group level:


1. Open the Failover Clustering console, select **Services and Applications**, and select the Resource Group that hosts the HA VM.
2. Right-click the **Virtual Machine** resource, select the **Advanced Policies** tab and de-select the cluster nodes that should not host this specific virtual machine.
3. Repeat step 2 for all the other resources (**Virtual Machine Configuration** and **Disk Drives**) in this resource group.


Converting an Existing Non-HA VM to a HA VM

The key requirement for a VM to be converted to a HA VM is that all of the VM's files (including VHDs) are on shared storage. "Implementing Hyper-V Host Clusters" walks through the high-level steps for configuring HA VMs if the VM's files are already on shared storage and the disks can be made cluster resources.

The following is high level guidance for converting a non-HA VM that has its files on a disk that cannot be made a Windows Server 2008 R2 Failover Cluster resource, such as a local disk on a server or a disk on an array that does not support Windows Server 2008 R2 Failover Clustering. In this scenario, the VM's files have to be moved from the current location to storage LUN(s) that can be made cluster resources. The recommended mechanism to move VM files is to use the Export/Import function in Hyper-V.

1. Provision a new storage LUN.
Bring the disk **online** on any one cluster node, **initialize** it, and format it as **NTFS**.
2. Use the Failover Cluster Management console to make this storage LUN a cluster resource. Make sure that this LUN is listed under **Storage→Available Storage**.
3. From the Hyper-V Manager Console, select the non-HA VM, and export the VM files to the newly provisioned storage LUN.

 **NOTE:** If the storage LUN cluster resource is not owned by this node, the storage LUN will need to be moved to the node that is currently running the VM before exporting the VM files.


 **NOTE:** If you want the VM on CSV volume then you need to export the VM on cluster shared volume, path appears on the system drive of the node, under the **\ClusterStorage** folder. All the LUN's in cluster shared volumes are mapped within this folder with a volume number.

4. After the export is complete, delete the existing non-HA VM using the Hyper-V Manager console.
5. Use the import function to import the VM files from the shared storage LUN to the same node.
6. Use the guidance provided under "Enabling VMs as HA VMs" to complete the configuration of the HA VM.


Converting an HA VM to a Non-HA VM

To convert a HA VM to a non-HA VM requires that the VM files be exported before the files are removed as cluster resources.

1. Use the Failover Cluster console to shut down or turn off the VM.

 **NOTE:** Do not initiate these actions from the Hyper-V Manager console because the cluster service will restart the VM to maintain the VM's HA state


2. From the Hyper-V Manager console, export the virtual machine to an alternate location (such as a local hard disk). Once the export is complete, delete the existing VM from Hyper-V Manager.
3. Use the Failover Clustering console to delete the VM resource group that is hosting the HA VM. The VHD files have to be deleted manually from the shared storage.
4. From the Hyper-V Manager console, import the virtual machine from the location to which it was exported in Step 2.

 **NOTE:** If the resource group of an HA VM is deleted prior to exporting the VM files as recommended above, Hyper-V Manager will de-register the VM and the VM will not be listed on the console even though the files are still available on the disk. There is no mechanism to re-register the VM. In such a scenario, the only recovery option is create a new virtual machine from the Hyper-V Manager console and attach the VM to the existing VHD files or passthrough disks.

Using SMB/CIFS Shares in Hyper-V

Hyper-V allows the use of SMB/CIFS shares (file shares) to host VM resources such as ISO files or VHDs. Use of SMB/CIFS shares is not recommended due to the performance limitations, but there might be certain scenarios that benefit from their use. Consider the following when implementing SMB shares in a HA environment:

- Best practice recommendation when using an SMB share in Hyper-V HA environments is to make sure that the file share is also a clustered resource so that it does not become a single point of failure in the highly available environment.
- It is strongly recommended that the file share be managed by a cluster that is separate from the Hyper-V Host Cluster. If the file server resources are also hosted by the same cluster, there may be issues during failover scenarios due to the file server resource not being online when the dependent HA VM resources come online. This is especially true when the same cluster node ends up owning the file server resource and the dependent HA VM resource. For more information on configuring a file server cluster, download the Microsoft document *Step-by-Step Guide for Configuring a Two-Node File Server Failover Cluster in Windows Server 2008 R2* from microsoft.com.
- When a VM that uses file shares is made a HA VM, the High Availability Wizard might generate a warning that the file shares are not clustered resources even when they are. This is known behavior and this warning can be ignored.
- When accessing SMB shares from the Hyper-V Hosts from UNC path, best practice is to use the DNS name of the server hosting the share rather than the IP address of the server hosting the share. For example, when mapping to a shared folder Share\$ on server FileServer.Domain.com, make sure that it is mapped using [\\FileServer.Domain.com\Share\\$](http://FileServer.Domain.com/Share$).


 **NOTE:** Hyper-V does not support file share access via a mapped drive.

- Grant the appropriate permissions for the domain "Machine" account of all the Hyper-V hosts that are part of the Hyper-V Host Cluster:
 - The domain machine accounts (such as DOMAIN\COMPUTERNAME\$) of all Hyper-V cluster nodes are granted **Full Control** in the **Share** permissions of the shared folder
 - The domain machine accounts of all Hyper-V cluster nodes are granted **Full Control** in the **Security** settings for the shared folder and all its files
- In certain scenarios (such as remotely managing a Hyper-V server), the use of SMB shares will require the use of constrained delegation. Refer to *Step-by-Step Guide for Configuring a Two-Node File Server Failover Cluster in Windows Server 2008 R2* from microsoft.com.
- Dell does not recommend the use of file shares to host VM files due to the performance limitations. However, if you are using file shares, using a separate NIC is recommended.

Using Mount Points in Hyper-V


Failover Clustering in Windows Server 2008 R2 allows a single cluster with up to 16 nodes. Therefore, you can have a single Hyper-V Host Cluster configuration of up to 16 servers. As shown in Figure 13, one of the most common mechanisms to provision virtual disks to virtual machines is using VHD files created on a formatted volume on a storage disk mounted in the parent partition with a drive letter.

Figure 13. Typical VHD Configuration on Storage Disk Assigned with a Drive Letter



In a Hyper-V Host Cluster configuration with many servers that host a large number of VHD-based virtual machines, there may not be a sufficient number of drive letters (A-Z) in the parent partition to host the storage LUNs. To work around this drive letter limitation, Hyper-V allows the use of Mount Points to host storage LUNs.

Figure 14. Typical VHD Configuration on Storage Disk Configured with a Mount Point



In Figure 14, LUN A is not assigned a separate drive letter in the parent partition, but is instead provisioned in the parent partition using the mount point C:\StorageDisk1. For specific step-by-step information on configuring mount points, refer to the Microsoft documentation at <http://support.microsoft.com/kb/947021>. Note that the use of mount points is an advanced technique to provision storage, and careful consideration should be taken before using it broadly.

In a Hyper-V Host Cluster environment, there are two additional requirements prior to successfully deploying HA VMs Hosts on mount points:

- The Hyper-V and Failover Cluster Integration QFE (Microsoft KB951308 from <http://support.microsoft.com>) has to be applied on all Hyper-V nodes as well as systems running the Failover Cluster Management console. This is required for the High Availability wizard to detect that virtual machine files are on a volume that is using a mount point and not a drive letter.
- If any one of the Hyper-V nodes has a volume using a mount point, it is essential that all the Hyper-V nodes that are part of that Hyper-V Host Cluster have a folder with the exact name so that a placeholder exists when the storage disk fails over to any of the nodes. For example, in a configuration similar to that shown in Figure 14, all nodes should have a folder C:\StorageDisk1.

Hyper-V Host Clustering Data Template

The templates below provide guidance for data sheets that may be created to record information on the Hyper-V Host Cluster deployment. Note that the sample information within the tables is only for guidance.

Table 9. Hyper-V Host Cluster Summary

Cluster Information	Cluster Solution
Hyper-V Host Cluster Name:	
Hyper-V Host Cluster IP Address:	
VM Workload Type:	
Location:	
Notes:	

Table 10. Hyper-V Host Cluster Nodes

Node Name	Service Tag	PowerEdge Server Model	Processor Info	Full or Core	Parent Partition/ Public IP Address	Private IP Address

Table 11. Hyper-V Host Cluster Network

Node Name	Physical NIC Information	Type	IP Address	Notes
	LOM #1	Host Management NIC & Cluster Public		
	LOM #2	Hyper-V Virtual Network		
	LOM #1	Hyper-V Virtual Network		
	LOM #2	Live Migration		
	LOM #3	iSCSI Storage NIC		
	LOM #4	Cluster Private		
	LOM #5	iSCSI Storage NIC		

Table 12. Hyper-V Host Cluster HA VM Resource Group Information

VM Resource Group	VMs in Resource Group	Storage LUN Resources	Notes
Group-A-VMs	VM#1	Cluster Disk 1 Cluster Disk 2	
Group-B-VMs	VM#2 VM#3	Cluster Disk 3 Cluster Disk 3 Cluster Disk 4	

References

- Dell Solutions for Windows Server 2008 R2 Hyper-V at www.dell.com/hyper-v
 - Dell Virtualization Solutions Advisor Tool
 - Dell Solutions Overview Guide for Microsoft Hyper-V
 - Dell Networking Solutions Guide for Microsoft Hyper-V
 - Dell Storage Solutions Guide for Microsoft Hyper-V
 - Dell Virtualization Reference Architecture for Microsoft Hyper-V
- Dell High Availability Cluster Solutions documentation at <http://docs.us.dell.com/support/edocs/systems/clusters>
 - HA Cluster Solutions featuring Dell Compellent Storage Center Fiber Channel Storage
 - HA Cluster Solutions featuring Dell PowerVault Fiber Channel Storage
 - HA Cluster Solutions featuring Dell PowerVault SAS/SATA Storage
 - HA Cluster Solutions featuring Dell PowerVault and Dell Compellent Storage Center iSCSI Storage
 - HA Cluster Solutions featuring Dell | EqualLogic PS Series iSCSI Storage
- Failover Clustering in Windows Server 2008 R2 at www.microsoft.com/windowsserver2008/failover-clusters.msp
- Microsoft Step-by-Step Guide to Configure a Two-Node File Server Failover *Cluster* from www.microsoft.com
- Microsoft Step-by-Step Guide for Testing Hyper-V and Failover Clustering document at www.microsoft.com
- Hyper-V RTM Update - Microsoft KB950050 from <http://support.microsoft.com>
- Hyper-V and Failover Cluster Integration QFE - Microsoft KB951308 from <http://support.microsoft.com>
- Requirements and Limits for Virtual Machines and Hyper-V in Windows Server 2008 R2 document at [http://technet.microsoft.com/en-us/library/ee405267\(WS.10\).aspx](http://technet.microsoft.com/en-us/library/ee405267(WS.10).aspx)

Glossary

Failover Clustering Console — The Microsoft Management Console (MMC) that is used to manage the Failover Clustering feature (cluadmin.msc) in Windows Server 2008.

HA VM — A VM that has been configured as a Windows Failover Cluster resource.

Hyper-V Cluster Nodes — Windows Server 2008 R2 servers that have the Hyper-V role configured and are part of a failover cluster.

Hyper-V Manager Console — The Microsoft Management Console (MMC) that is used to manage the Hyper-V Virtualization Role on Windows Server 2008 R2.

LUN (Logical Unit Number) — In this solutions guide, a LUN refers to a unique disk that is provisioned to a server from a storage enclosure or array.

MPIO — Multi-Path IO provides fault-tolerance and performance enhancements by implementing more than one physical connection path from servers to storage.

Passthrough Disks — Physical disks (local disks or LUNs provisioned from SAN) that are configured directly to VMs.

VM — A Hyper-V Virtual Machine.